
Onan

UserFriendlyCDs

Parts Manual

BGE/BGEL

Emerald I GenSet



RV Electric Generating Set

965-0232 1-90 (BGE SPEC A-E) (BGEL SPEC B-D) Replaces 1-89 (BGE Spec A-E) (BGEL Spec B-D) Printed in U.S.A.

SAFETY PRECAUTIONS

The following symbols are used in Onan manuals to alert users to the potentially dangerous conditions relating to maintenance of the equipment and replacement of parts. Please read and observe.

ADANGER
This symbol warns of immediate hazards which will result in severe personal injury or death.

This symbol refers to a hazard or unsafe practice which can result in severe personal injury or death.

This symbol refers to a hazard or unsafe practice which can result in personal injury or product or property damage.

MODEL IDENTIFICATION

To avoid errors or delay in filling your parts order, always give the MODEL, SPEC NO., and SERIAL NO. from the Onan nameplate.

For handy reference, insert your nameplate information in the spaces below:

MODEL AND SPEC NO.

SERIAL NO.

PRODUCT SAFETY PRECAUTIONS

AWARNING

Contact with USED ENGINE OILS has been identified by a United States federal agency and some USA state agencies as causing CANCER or REPRODUCTIVE TOXICITY. When checking or changing engine oils take all necessary precautions not to ingest, breathe the fumes or contact the used oil.

AWARNING

Contact with ASBESTOS has been identified by a United States federal agency and some USA state agencies as causing CANCER or REPRODUCTIVE TOXICITY. When handling engine gaskets take all necessary precautions not to ingest, breathe or contact the dust from the gaskets! Use adequate ventilation and wear protective gloves, masks and clothing!

AWARNING

Contact with BENZINE and LEAD, found in gasoline, fuel additives and solvents has been identified by a United States federal agency and some USA agencies as causing CANCER or REPRODUCTIVE TOXICITY. When checking, draining or adding gasoline and fuel additives, or using solvents take all necessary precautions not to ingest, breathe the fumes, or contact the liquids. Use adequate ventilation and wear protective gloves, masks and clothing!

Index

Adapter, Cleaner - Air 14,16	Floment Classes Air 14 16
	Element, Cleaner - Air 14,16
Adapter, Filter - Oil 12	Element, Filter - Fuel 16
Adapter, Generator 38	
Adapter, Preheater 14	Fan and Gear, Armature 38
Armature, Wound 38	Filter, LPG 16
	Filter, Oil 12
Backplate, Scroll 30	Filter, Tube - Breather 4
Baffle, Valve - Breather 4	
Dallie, valve bleather 4	Flywheel 9
Ball, Fly - Governor 8	Fuse 40
Bar, Bus 28	
Base, Box - Breaker 23	Gasket, Adapter - Oil Filter 12
Base, 0il 10	Gasket, Base - Oil 10
Bearing, Ball 13,38	Gasket, Plate - Bearing 4
Bearing, Camshaft 4	Gasket, Box - Breaker 22,23
Bearing, Crankshaft 4	Gasket, Exhaust 32,34
Bi-Metal, Choke .14	Gasket, Head - Cylinder 4
Block, Cylinder 4	Gasket, Horn - Air 14,16
Block, Generator 38	Gasket Kit, Pump - Oil 6
Block, Terminal 38	Gasket, Manifold - Exhaust 32,34
Board, Circuit - Printed 40	Gasket, Manifold - Intake 14,16
Bolt, Rod - Connecting 6	Gasket, Mounting - Breaker Box 22,23
Box, Breaker 22,23	Gasket, Mounting - Carburetor 14,16
Brace, Rear 36	Cooket Mounting Cooker 12
	Gasket, Mounting - Gearcase 13
Brace, Side 36	Gasket, Plug - Oil Drain 10
Bracket, Governor 21	Gasket, Cover - Valve 4
Bracket, Exhaust 32,34	Gear, Camshaft 8
Bracket, Housing 36	Gearcase 13
Bracket, Lifting 30	Gear, Crankshaft 9
Bracket, Manifold – Exhaust 33,35	Gear, Ring 38
Procket Mounting - Dischage 14	
Bracket, Mounting - Diaphragm 14	Generator 38
Bracket, Mounting - Fuel 16	Governor 21
Bracket, Mounting - Housing 14,16	Grommet, Rubber 36
Didokot, Modriting Housing 14,10	
Bracket, Mounting - Resistor 27	Guard, Breaker - Circuit 40
Bracket, Pump - Fuel 14	Guard, Scroll 30
Breaker, Circuit 40	
	Guide, Valve 4
Brush, Generator 38	
	Honor Fubrust 20 34
Brush, Generator 38 Bushing 40	Hanger, Exhaust 32,34
Bushing 40	Harness, Wiring 40
Bushing 40 Cable, Plug - Spark 22	Harness, Wiring 40 Harness, Wiring - Remote 42
Bushing 40 Cable, Plug - Spark 22 Camshaft 8	Harness, Wiring 40
Bushing 40 Cable, Plug - Spark 22 Camshaft 8	Harness, Wiring 40 Harness, Wiring – Remote 42 Head, Cylinder 4
Bushing 40 Cable, Plug - Spark 22 Camshaft 8 Cap, Fill - Oil 10	Harness, Wiring 40 Harness, Wiring – Remote 42 Head, Cylinder 4 Holder, Fuse 40
Bushing 40 Cable, Plug - Spark 22 Camshaft 8 Cap, Fill - Oil 10 Cap, Insulating 28	Harness, Wiring 40 Harness, Wiring - Remote 42 Head, Cylinder 4 Holder, Fuse 40 Housing, Air 30
Bushing 40 Cable, Plug - Spark 22 Camshaft 8 Cap, Fill - Oil 10 Cap, Insulating 28	Harness, Wiring 40 Harness, Wiring - Remote 42 Head, Cylinder 4 Holder, Fuse 40 Housing, Air 30
Bushing 40 Cable, Plug - Spark 22 Camshaft 8 Cap, Fill - Oil 10 Cap, Insulating 28 Cap and Valve, Breather 6	Harness, Wiring 40 Harness, Wiring - Remote 42 Head, Cylinder 4 Holder, Fuse 40 Housing, Air 30 Housing, Below Floor 36
Bushing 40 Cable, Plug - Spark 22 Camshaft 8 Cap, Fill - Oil 10 Cap, Insulating 28 Cap and Valve, Breather 6 Carburetor Components (Gasoline) 19,20	Harness, Wiring 40 Harness, Wiring - Remote 42 Head, Cylinder 4 Holder, Fuse 40 Housing, Air 30 Housing, Below Floor 36 Housing, Breather 4
Bushing 40 Cable, Plug - Spark 22 Camshaft 8 Cap, Fill - Oil 10 Cap, Insulating 28 Cap and Valve, Breather 6	Harness, Wiring 40 Harness, Wiring - Remote 42 Head, Cylinder 4 Holder, Fuse 40 Housing, Air 30 Housing, Below Floor 36 Housing, Breather 4
Bushing 40 Cable, Plug - Spark 22 Camshaft 8 Cap, Fill - Oil 10 Cap, Insulating 28 Cap and Valve, Breather 6 Carburetor Components (Gasoline) 19,20 Carburetor Components (LP) 18	Harness, Wiring 40 Harness, Wiring - Remote 42 Head, Cylinder 4 Holder, Fuse 40 Housing, Air 30 Housing, Below Floor 36 Housing, Breather 4 Housing, Cleaner - Air 14,16
Bushing 40 Cable, Plug - Spark 22 Camshaft 8 Cap, Fill - Oil 10 Cap, Insulating 28 Cap and Valve, Breather 6 Carburetor Components (Gasoline) 19,20 Carburetor Components (LP) 18 Carburetor, Gasoline 14	Harness, Wiring 40 Harness, Wiring - Remote 42 Head, Cylinder 4 Holder, Fuse 40 Housing, Air 30 Housing, Below Floor 36 Housing, Breather 4 Housing, Cleaner - Air 14,16 Housing, Cylinder - Air 30
Bushing 40 Cable, Plug - Spark 22 Camshaft 8 Cap, Fill - Oil 10 Cap, Insulating 28 Cap and Valve, Breather 6 Carburetor Components (Gasoline) 19,20 Carburetor Components (LP) 18 Carburetor, Gasoline 14 Carburetor, LP 16	Harness, Wiring 40 Harness, Wiring - Remote 42 Head, Cylinder 4 Holder, Fuse 40 Housing, Air 30 Housing, Below Floor 36 Housing, Breather 4 Housing, Cleaner - Air 14,16 Housing, Cylinder - Air 30 Housing, Choke 14
Bushing 40 Cable, Plug - Spark 22 Camshaft 8 Cap, Fill - Oil 10 Cap, Insulating 28 Cap and Valve, Breather 6 Carburetor Components (Gasoline) 19,20 Carburetor Components (LP) 18 Carburetor, Gasoline 14 Carburetor, LP 16	Harness, Wiring 40 Harness, Wiring - Remote 42 Head, Cylinder 4 Holder, Fuse 40 Housing, Air 30 Housing, Below Floor 36 Housing, Breather 4 Housing, Cleaner - Air 14,16 Housing, Cylinder - Air 30 Housing, Choke 14
Bushing 40 Cable, Plug - Spark 22 Camshaft 8 Cap, Fill - Oil 10 Cap, Insulating 28 Cap and Valve, Breather 6 Carburetor Components (Gasoline) 19,20 Carburetor Components (LP) 18 Carburetor, Gasoline 14 Carburetor, LP 16 Clamp, Coil 22	Harness, Wiring 40 Harness, Wiring - Remote 42 Head, Cylinder 4 Holder, Fuse 40 Housing, Air 30 Housing, Below Floor 36 Housing, Breather 4 Housing, Cleaner - Air 14,16 Housing, Cylinder - Air 30 Housing, Choke 14 Housing, Connector 40,42
Bushing 40 Cable, Plug - Spark 22 Camshaft 8 Cap, Fill - Oil 10 Cap, Insulating 28 Cap and Valve, Breather 6 Carburetor Components (Gasoline) 19,20 Carburetor Components (LP) 18 Carburetor, Gasoline 14 Carburetor, LP 16 Clamp, Coil 22 Clamp, Muffler 32,34	Harness, Wiring 40 Harness, Wiring - Remote 42 Head, Cylinder 4 Holder, Fuse 40 Housing, Air 30 Housing, Below Floor 36 Housing, Breather 4 Housing, Cleaner - Air 14,16 Housing, Cylinder - Air 30 Housing, Choke 14 Housing, Connector 40,42 Housing, Socket 40
Bushing 40 Cable, Plug - Spark 22 Camshaft 8 Cap, Fill - Oil 10 Cap, Insulating 28 Cap and Valve, Breather 6 Carburetor Components (Gasoline) 19,20 Carburetor Components (LP) 18 Carburetor, Gasoline 14 Carburetor, LP 16 Clamp, Coil 22 Clamp, Muffler 32,34 Clip, Cover - Breaker Box 23	Harness, Wiring 40 Harness, Wiring - Remote 42 Head, Cylinder 4 Holder, Fuse 40 Housing, Air 30 Housing, Below Floor 36 Housing, Breather 4 Housing, Cleaner - Air 14,16 Housing, Cylinder - Air 30 Housing, Choke 14 Housing, Connector 40,42 Housing, Socket 40
Bushing 40 Cable, Plug - Spark 22 Camshaft 8 Cap, Fill - Oil 10 Cap, Insulating 28 Cap and Valve, Breather 6 Carburetor Components (Gasoline) 19,20 Carburetor Components (LP) 18 Carburetor, Gasoline 14 Carburetor, LP 16 Clamp, Coil 22 Clamp, Muffler 32,34 Clip, Cover - Breaker Box 23	Harness, Wiring 40 Harness, Wiring - Remote 42 Head, Cylinder 4 Holder, Fuse 40 Housing, Air 30 Housing, Below Floor 36 Housing, Breather 4 Housing, Cleaner - Air 14,16 Housing, Cylinder - Air 30 Housing, Choke 14 Housing, Connector 40,42 Housing, Socket 40 Housing, Stator 38
Bushing 40 Cable, Plug - Spark 22 Camshaft 8 Cap, Fill - Oil 10 Cap, Insulating 28 Cap and Valve, Breather 6 Carburetor Components (Gasoline) 19,20 Carburetor Components (LP) 18 Carburetor, Gasoline 14 Carburetor, LP 16 Clamp, Coil 22 Clamp, Muffler 32,34 Clip, Cover - Breaker Box 23 Clip, Housing - Choke 14	Harness, Wiring 40 Harness, Wiring - Remote 42 Head, Cylinder 4 Holder, Fuse 40 Housing, Air 30 Housing, Below Floor 36 Housing, Breather 4 Housing, Cleaner - Air 14,16 Housing, Cylinder - Air 30 Housing, Choke 14 Housing, Connector 40,42 Housing, Socket 40 Housing, Stator 38 Hose, Fuel 16
Bushing 40 Cable, Plug - Spark 22 Camshaft 8 Cap, Fill - Oil 10 Cap, Insulating 28 Cap and Valve, Breather 6 Carburetor Components (Gasoline) 19,20 Carburetor Components (LP) 18 Carburetor, Gasoline 14 Carburetor, LP 16 Clamp, Coil 22 Clamp, Muffler 32,34 Clip, Cover - Breaker Box 23 Clip, Housing - Choke 14 Coil, Ignition 22	Harness, Wiring 40 Harness, Wiring - Remote 42 Head, Cylinder 4 Holder, Fuse 40 Housing, Air 30 Housing, Below Floor 36 Housing, Breather 4 Housing, Cleaner - Air 14,16 Housing, Cylinder - Air 30 Housing, Choke 14 Housing, Connector 40,42 Housing, Socket 40 Housing, Stator 38 Hose, Fuel 16 Hose, Preheater 14
Bushing 40 Cable, Plug - Spark 22 Camshaft 8 Cap, Fill - Oil 10 Cap, Insulating 28 Cap and Valve, Breather 6 Carburetor Components (Gasoline) 19,20 Carburetor Components (LP) 18 Carburetor, Gasoline 14 Carburetor, LP 16 Clamp, Coil 22 Clamp, Muffler 32,34 Clip, Cover - Breaker Box 23 Clip, Housing - Choke 14 Coil, Ignition 22	Harness, Wiring 40 Harness, Wiring - Remote 42 Head, Cylinder 4 Holder, Fuse 40 Housing, Air 30 Housing, Below Floor 36 Housing, Breather 4 Housing, Cleaner - Air 14,16 Housing, Cylinder - Air 30 Housing, Choke 14 Housing, Connector 40,42 Housing, Socket 40 Housing, Stator 38 Hose, Fuel 16 Hose, Preheater 14
Bushing 40 Cable, Plug - Spark 22 Camshaft 8 Cap, Fill - Oil 10 Cap, Insulating 28 Cap and Valve, Breather 6 Carburetor Components (Gasoline) 19,20 Carburetor Components (LP) 18 Carburetor, Gasoline 14 Carburetor, LP 16 Clamp, Coil 22 Clamp, Muffler 32,34 Clip, Cover - Breaker Box 23 Clip, Housing - Choke 14 Coil, Ignition 22 Condenser, Ignition 22,23	Harness, Wiring 40 Harness, Wiring - Remote 42 Head, Cylinder 4 Holder, Fuse 40 Housing, Air 30 Housing, Below Floor 36 Housing, Breather 4 Housing, Cleaner - Air 14,16 Housing, Cylinder - Air 30 Housing, Choke 14 Housing, Connector 40,42 Housing, Socket 40 Housing, Stator 38 Hose, Fuel 16 Hose, Vacuum 14
Bushing 40 Cable, Plug - Spark 22 Camshaft 8 Cap, Fill - Oil 10 Cap, Insulating 28 Cap and Valve, Breather 6 Carburetor Components (Gasoline) 19,20 Carburetor Components (LP) 18 Carburetor, Gasoline 14 Carburetor, LP 16 Clamp, Coil 22 Clamp, Muffler 32,34 Clip, Cover - Breaker Box 23 Clip, Housing - Choke 14 Coil, Ignition 22 Condenser, Ignition 22,23 Connector, Parallel 28	Harness, Wiring 40 Harness, Wiring - Remote 42 Head, Cylinder 4 Holder, Fuse 40 Housing, Air 30 Housing, Below Floor 36 Housing, Breather 4 Housing, Cleaner - Air 14,16 Housing, Cylinder - Air 30 Housing, Choke 14 Housing, Connector 40,42 Housing, Socket 40 Housing, Stator 38 Hose, Fuel 16 Hose, Preheater 14
Bushing 40 Cable, Plug - Spark 22 Camshaft 8 Cap, Fill - Oil 10 Cap, Insulating 28 Cap and Valve, Breather 6 Carburetor Components (Gasoline) 19,20 Carburetor Components (LP) 18 Carburetor, Gasoline 14 Carburetor, LP 16 Clamp, Coil 22 Clamp, Muffler 32,34 Clip, Cover - Breaker Box 23 Clip, Housing - Choke 14 Coil, Ignition 22 Condenser, Ignition 22,23 Connector, Parallel 28 Connector, Eight Pin 40	Harness, Wiring 40 Harness, Wiring - Remote 42 Head, Cylinder 4 Holder, Fuse 40 Housing, Air 30 Housing, Below Floor 36 Housing, Breather 4 Housing, Cleaner - Air 14,16 Housing, Cylinder - Air 30 Housing, Choke 14 Housing, Connector 40,42 Housing, Socket 40 Housing, Stator 38 Hose, Fuel 16 Hose, Vacuum 14
Bushing 40 Cable, Plug - Spark 22 Camshaft 8 Cap, Fill - Oil 10 Cap, Insulating 28 Cap and Valve, Breather 6 Carburetor Components (Gasoline) 19,20 Carburetor Components (LP) 18 Carburetor, Gasoline 14 Carburetor, LP 16 Clamp, Coil 22 Clamp, Muffler 32,34 Clip, Cover - Breaker Box 23 Clip, Housing - Choke 14 Coil, Ignition 22 Condenser, Ignition 22,23 Connector, Parallel 28 Connector, Eight Pin 40	Harness, Wiring 40 Harness, Wiring - Remote 42 Head, Cylinder 4 Holder, Fuse 40 Housing, Air 30 Housing, Below Floor 36 Housing, Breather 4 Housing, Cleaner - Air 14,16 Housing, Cylinder - Air 30 Housing, Choke 14 Housing, Connector 40,42 Housing, Socket 40 Housing, Stator 38 Hose, Fuel 16 Hose, Preheater 14 Hose, Vacuum 14 Hub, Cup - Governor 8
Bushing 40 Cable, Plug - Spark 22 Camshaft 8 Cap, Fill - Oil 10 Cap, Insulating 28 Cap and Valve, Breather 6 Carburetor Components (Gasoline) 19,20 Carburetor Components (LP) 18 Carburetor, Gasoline 14 Carburetor, LP 16 Clamp, Coil 22 Clamp, Muffler 32,34 Clip, Cover - Breaker Box 23 Clip, Housing - Choke 14 Coil, Ignition 22 Condenser, Ignition 22,23 Connector, Parallel 28 Connector, Eight Pin 40 Connector, Receptacle 38	Harness, Wiring 40 Harness, Wiring - Remote 42 Head, Cylinder 4 Holder, Fuse 40 Housing, Air 30 Housing, Below Floor 36 Housing, Breather 4 Housing, Cleaner - Air 14,16 Housing, Cylinder - Air 30 Housing, Choke 14 Housing, Connector 40,42 Housing, Socket 40 Housing, Stator 38 Hose, Fuel 16 Hose, Preheater 14 Hose, Vacuum 14 Hub, Cup - Governor 8 Index, Numerical 44,45,46,47
Bushing 40 Cable, Plug - Spark 22 Camshaft 8 Cap, Fill - Oil 10 Cap, Insulating 28 Cap and Valve, Breather 6 Carburetor Components (Gasoline) 19,20 Carburetor Components (LP) 18 Carburetor, Gasoline 14 Carburetor, LP 16 Clamp, Coil 22 Clamp, Muffler 32,34 Clip, Cover - Breaker Box 23 Clip, Housing - Choke 14 Coil, Ignition 22 Condenser, Ignition 22,23 Connector, Parallel 28 Connector, Eight Pin 40 Connector, Receptacle 38 Connector, Tab 38	Harness, Wiring 40 Harness, Wiring - Remote 42 Head, Cylinder 4 Holder, Fuse 40 Housing, Air 30 Housing, Below Floor 36 Housing, Breather 4 Housing, Cleaner - Air 14,16 Housing, Cylinder - Air 30 Housing, Choke 14 Housing, Connector 40,42 Housing, Socket 40 Housing, Stator 38 Hose, Fuel 16 Hose, Preheater 14 Hose, Vacuum 14 Hub, Cup - Governor 8
Bushing 40 Cable, Plug - Spark 22 Camshaft 8 Cap, Fill - Oil 10 Cap, Insulating 28 Cap and Valve, Breather 6 Carburetor Components (Gasoline) 19,20 Carburetor Components (LP) 18 Carburetor, Gasoline 14 Carburetor, LP 16 Clamp, Coil 22 Clamp, Muffler 32,34 Clip, Cover - Breaker Box 23 Clip, Housing - Choke 14 Coil, Ignition 22 Condenser, Ignition 22,23 Connector, Parallel 28 Connector, Eight Pin 40 Connector, Receptacle 38 Connector, Tab 38	Harness, Wiring 40 Harness, Wiring - Remote 42 Head, Cylinder 4 Holder, Fuse 40 Housing, Air 30 Housing, Below Floor 36 Housing, Breather 4 Housing, Cleaner - Air 14,16 Housing, Cylinder - Air 30 Housing, Choke 14 Housing, Connector 40,42 Housing, Socket 40 Housing, Stator 38 Hose, Fuel 16 Hose, Preheater 14 Hose, Vacuum 14 Hub, Cup - Governor 8 Index, Numerical 44,45,46,47 Insert, Valve Seat 4
Bushing 40 Cable, Plug - Spark 22 Camshaft 8 Cap, Fill - Oil 10 Cap, Insulating 28 Cap and Valve, Breather 6 Carburetor Components (Gasoline) 19,20 Carburetor Components (LP) 18 Carburetor, Gasoline 14 Carburetor, LP 16 Clamp, Coil 22 Clamp, Muffler 32,34 Clip, Cover - Breaker Box 23 Clip, Housing - Choke 14 Coil, Ignition 22 Condenser, Ignition 22,23 Connector, Parallel 28 Connector, Eight Pin 40 Connector, Receptacle 38 Connector, Tab 38 Control, Start - Remote 42	Harness, Wiring 40 Harness, Wiring - Remote 42 Head, Cylinder 4 Holder, Fuse 40 Housing, Air 30 Housing, Below Floor 36 Housing, Breather 4 Housing, Cleaner - Air 14,16 Housing, Cylinder - Air 30 Housing, Choke 14 Housing, Connector 40,42 Housing, Socket 40 Housing, Stator 38 Hose, Fuel 16 Hose, Preheater 14 Hose, Vacuum 14 Hub, Cup - Governor 8 Index, Numerical 44,45,46,47 Insert, Valve Seat 4 Insulator, Fuse 40
Bushing 40 Cable, Plug - Spark 22 Camshaft 8 Cap, Fill - Oil 10 Cap, Insulating 28 Cap and Valve, Breather 6 Carburetor Components (Gasoline) 19,20 Carburetor Components (LP) 18 Carburetor, Gasoline 14 Carburetor, LP 16 Clamp, Coil 22 Clamp, Muffler 32,34 Clip, Cover - Breaker Box 23 Clip, Housing - Choke 14 Coil, Ignition 22 Condenser, Ignition 22,23 Connector, Parallel 28 Connector, Receptacle 38 Connector, Tab 38 Control, Start - Remote 42 Cover, Block - Brush 38	Harness, Wiring 40 Harness, Wiring - Remote 42 Head, Cylinder 4 Holder, Fuse 40 Housing, Air 30 Housing, Below Floor 36 Housing, Breather 4 Housing, Cleaner - Air 14,16 Housing, Cylinder - Air 30 Housing, Connector 40,42 Housing, Connector 40,42 Housing, Socket 40 Housing, Stator 38 Hose, Fuel 16 Hose, Preheater 14 Hose, Vacuum 14 Hub, Cup - Governor 8 Index, Numerical 44,45,46,47 Insert, Valve Seat 4 Insulator, Fuse 40 Insulator, Terminal - Start Solenoid 40
Bushing 40 Cable, Plug - Spark 22 Camshaft 8 Cap, Fill - Oil 10 Cap, Insulating 28 Cap and Valve, Breather 6 Carburetor Components (Gasoline) 19,20 Carburetor Components (LP) 18 Carburetor, Gasoline 14 Carburetor, LP 16 Clamp, Coil 22 Clamp, Muffler 32,34 Clip, Cover - Breaker Box 23 Clip, Housing - Choke 14 Coil, Ignition 22 Condenser, Ignition 22,23 Connector, Parallel 28 Connector, Eight Pin 40 Connector, Receptacle 38 Connector, Tab 38 Control, Start - Remote 42 Cover, Block - Brush 38 Cover, Box - Breaker 23	Harness, Wiring 40 Harness, Wiring - Remote 42 Head, Cylinder 4 Holder, Fuse 40 Housing, Air 30 Housing, Below Floor 36 Housing, Breather 4 Housing, Cleaner - Air 14,16 Housing, Cylinder - Air 30 Housing, Choke 14 Housing, Connector 40,42 Housing, Socket 40 Housing, Stator 38 Hose, Fuel 16 Hose, Preheater 14 Hose, Vacuum 14 Hub, Cup - Governor 8 Index, Numerical 44,45,46,47 Insert, Valve Seat 4 Insulator, Fuse 40
Bushing 40 Cable, Plug - Spark 22 Camshaft 8 Cap, Fill - Oil 10 Cap, Insulating 28 Cap and Valve, Breather 6 Carburetor Components (Gasoline) 19,20 Carburetor Components (LP) 18 Carburetor, Gasoline 14 Carburetor, LP 16 Clamp, Coil 22 Clamp, Muffler 32,34 Clip, Cover - Breaker Box 23 Clip, Housing - Choke 14 Coil, Ignition 22 Condenser, Ignition 22,23 Connector, Parallel 28 Connector, Eight Pin 40 Connector, Receptacle 38 Connector, Tab 38 Control, Start - Remote 42 Cover, Block - Brush 38 Cover, Box - Breaker 23	Harness, Wiring 40 Harness, Wiring - Remote 42 Head, Cylinder 4 Holder, Fuse 40 Housing, Air 30 Housing, Below Floor 36 Housing, Breather 4 Housing, Cleaner - Air 14,16 Housing, Cylinder - Air 30 Housing, Connector 40,42 Housing, Connector 40,42 Housing, Socket 40 Housing, Stator 38 Hose, Fuel 16 Hose, Preheater 14 Hose, Vacuum 14 Hub, Cup - Governor 8 Index, Numerical 44,45,46,47 Insert, Valve Seat 4 Insulator, Fuse 40 Insulator, Terminal - Start Solenoid 40
Cable, Plug - Spark 22 Camshaft 8 Cap, Fill - Oil 10 Cap, Insulating 28 Cap and Valve, Breather 6 Carburetor Components (Gasoline) 19,20 Carburetor Components (LP) 18 Carburetor, Gasoline 14 Carburetor, LP 16 Clamp, Coil 22 Clamp, Muffler 32,34 Clip, Cover - Breaker Box 23 Clip, Housing - Choke 14 Coil, Ignition 22 Condenser, Ignition 22,23 Connector, Parallel 28 Connector, Eight Pin 40 Connector, Receptacle 38 Connector, Tab 38 Control, Start - Remote 42 Cover, Block - Brush 38 Cover, Box - Breaker 23 Cover, Control 40	Harness, Wiring 40 Harness, Wiring - Remote 42 Head, Cylinder 4 Holder, Fuse 40 Housing, Air 30 Housing, Below Floor 36 Housing, Breather 4 Housing, Cleaner - Air 14,16 Housing, Cylinder - Air 30 Housing, Connector 40,42 Housing, Connector 38 Hose, Fuel 16 Hose, Preheater 14 Hose, Vacuum 14 Hub, Cup - Governor 8 Index, Numerical 44,45,46,47 Insert, Valve Seat 4 Insulator, Fuse 40 Insulator, Terminal - Start Solenoid 40 Isolator, Vibration 10
Bushing 40 Cable, Plug - Spark 22 Camshaft 8 Cap, Fill - Oil 10 Cap, Insulating 28 Cap and Valve, Breather 6 Carburetor Components (Gasoline) 19,20 Carburetor Components (LP) 18 Carburetor, Gasoline 14 Carburetor, LP 16 Clamp, Coil 22 Clamp, Muffler 32,34 Clip, Cover - Breaker Box 23 Clip, Housing - Choke 14 Coil, Ignition 22 Condenser, Ignition 22,23 Connector, Parallel 28 Connector, Eight Pin 40 Connector, Receptacle 38 Connector, Tab 38 Control, Start - Remote 42 Cover, Block - Brush 38 Cover, Box - Breaker 23 Cover, Control 40 Cover, Housing - Choke 14	Harness, Wiring 40 Harness, Wiring - Remote 42 Head, Cylinder 4 Holder, Fuse 40 Housing, Air 30 Housing, Below Floor 36 Housing, Breather 4 Housing, Cleaner - Air 14,16 Housing, Cylinder - Air 30 Housing, Connector 40,42 Housing, Connector 40,42 Housing, Socket 40 Housing, Stator 38 Hose, Fuel 16 Hose, Preheater 14 Hose, Vacuum 14 Hub, Cup - Governor 8 Index, Numerical 44,45,46,47 Insert, Valve Seat 4 Insulator, Fuse 40 Insulator, Terminal - Start Solenoid 40
Cable, Plug - Spark 22 Camshaft 8 Cap, Fill - Oil 10 Cap, Insulating 28 Cap and Valve, Breather 6 Carburetor Components (Gasoline) 19,20 Carburetor Components (LP) 18 Carburetor, Gasoline 14 Carburetor, LP 16 Clamp, Coil 22 Clamp, Muffler 32,34 Clip, Cover - Breaker Box 23 Clip, Housing - Choke 14 Coil, Ignition 22 Condenser, Ignition 22,23 Connector, Parallel 28 Connector, Eight Pin 40 Connector, Receptacle 38 Connector, Tab 38 Control, Start - Remote 42 Cover, Block - Brush 38 Cover, Box - Breaker 23 Cover, Control 40	Harness, Wiring 40 Harness, Wiring - Remote 42 Head, Cylinder 4 Holder, Fuse 40 Housing, Air 30 Housing, Below Floor 36 Housing, Breather 4 Housing, Cleaner - Air 14,16 Housing, Cylinder - Air 30 Housing, Connector 40,42 Housing, Connector 38 Hose, Fuel 16 Hose, Preheater 14 Hose, Vacuum 14 Hub, Cup - Governor 8 Index, Numerical 44,45,46,47 Insert, Valve Seat 4 Insulator, Fuse 40 Insulator, Terminal - Start Solenoid 40 Isolator, Vibration 10
Bushing 40 Cable, Plug - Spark 22 Camshaft 8 Cap, Fill - Oil 10 Cap, Insulating 28 Cap and Valve, Breather 6 Carburetor Components (Gasoline) 19,20 Carburetor Components (LP) 18 Carburetor, Gasoline 14 Carburetor, LP 16 Clamp, Coil 22 Clamp, Muffler 32,34 Clip, Cover - Breaker Box 23 Clip, Housing - Choke 14 Coil, Ignition 22 Condenser, Ignition 22,23 Connector, Parallel 28 Connector, Eight Pin 40 Connector, Receptacle 38 Connector, Tab 38 Control, Start - Remote 42 Cover, Block - Brush 38 Cover, Box - Breaker 23 Cover, Control 40 Cover, Housing - Choke 14 Cover, Housing - Choke 14 Cover, Transformer 38	Harness, Wiring 40 Harness, Wiring - Remote 42 Head, Cylinder 4 Holder, Fuse 40 Housing, Air 30 Housing, Below Floor 36 Housing, Breather 4 Housing, Cleaner - Air 14,16 Housing, Cylinder - Air 30 Housing, Choke 14 Housing, Connector 40,42 Housing, Socket 40 Housing, Stator 38 Hose, Fuel 16 Hose, Preheater 14 Hose, Vacuum 14 Hub, Cup - Governor 8 Index, Numerical 44,45,46,47 Insert, Valve Seat 4 Insulator, Fuse 40 Insulator, Terminal - Start Solenoid 40 Isolator, Vibration 10 Joint, Ball 21
Bushing 40 Cable, Plug - Spark 22 Camshaft 8 Cap, Fill - Oil 10 Cap, Insulating 28 Cap and Valve, Breather 6 Carburetor Components (Gasoline) 19,20 Carburetor Components (LP) 18 Carburetor, Gasoline 14 Carburetor, LP 16 Clamp, Coil 22 Clamp, Muffler 32,34 Clip, Cover - Breaker Box 23 Clip, Housing - Choke 14 Coil, Ignition 22 Condenser, Ignition 22,23 Connector, Parallel 28 Connector, Eight Pin 40 Connector, Receptacle 38 Connector, Tab 38 Control, Start - Remote 42 Cover, Block - Brush 38 Cover, Box - Breaker 23 Cover, Control 40 Cover, Housing - Choke 14 Cover, Transformer 38 Crankshaft 9	Harness, Wiring 40 Harness, Wiring - Remote 42 Head, Cylinder 4 Holder, Fuse 40 Housing, Air 30 Housing, Below Floor 36 Housing, Breather 4 Housing, Cleaner - Air 14,16 Housing, Cylinder - Air 30 Housing, Choke 14 Housing, Connector 40,42 Housing, Socket 40 Housing, Stator 38 Hose, Fuel 16 Hose, Preheater 14 Hose, Vacuum 14 Hub, Cup - Governor 8 Index, Numerical 44,45,46,47 Insert, Valve Seat 4 Insulator, Fuse 40 Insulator, Terminal - Start Solenoid 40 Isolator, Vibration 10 Joint, Ball 21 Key, Gear - Crankshaft 9
Bushing 40 Cable, Plug - Spark 22 Camshaft 8 Cap, Fill - Oil 10 Cap, Insulating 28 Cap and Valve, Breather 6 Carburetor Components (Gasoline) 19,20 Carburetor, Gasoline 14 Carburetor, LP 16 Clamp, Coil 22 Clamp, Muffler 32,34 Clip, Cover - Breaker Box 23 Clip, Housing - Choke 14 Coil, Ignition 22 Condenser, Ignition 22,23 Connector, Parallel 28 Connector, Eight Pin 40 Connector, Receptacle 38 Connector, Tab 38 Control, Start - Remote 42 Cover, Block - Brush 38 Cover, Box - Breaker 23 Cover, Control 40 Cover, Housing - Choke 14 Cover, Transformer 38 Crankshaft 9 Cup, Governor 8	Harness, Wiring 40 Harness, Wiring - Remote 42 Head, Cylinder 4 Holder, Fuse 40 Housing, Air 30 Housing, Below Floor 36 Housing, Breather 4 Housing, Cleaner - Air 14,16 Housing, Cylinder - Air 30 Housing, Choke 14 Housing, Connector 40,42 Housing, Socket 40 Housing, Stator 38 Hose, Fuel 16 Hose, Preheater 14 Hose, Vacuum 14 Hub, Cup - Governor 8 Index, Numerical 44,45,46,47 Insert, Valve Seat 4 Insulator, Fuse 40 Insulator, Terminal - Start Solenoid 40 Isolator, Vibration 10 Joint, Ball 21 Key, Gear - Crankshaft 9
Bushing 40 Cable, Plug - Spark 22 Camshaft 8 Cap, Fill - Oil 10 Cap, Insulating 28 Cap and Valve, Breather 6 Carburetor Components (Gasoline) 19,20 Carburetor, Gasoline 14 Carburetor, LP 16 Clamp, Coil 22 Clamp, Muffler 32,34 Clip, Cover - Breaker Box 23 Clip, Housing - Choke 14 Coil, Ignition 22 Condenser, Ignition 22,23 Connector, Parallel 28 Connector, Eight Pin 40 Connector, Receptacle 38 Connector, Tab 38 Control, Start - Remote 42 Cover, Block - Brush 38 Cover, Box - Breaker 23 Cover, Control 40 Cover, Housing - Choke 14 Cover, Transformer 38 Crankshaft 9 Cup, Governor 8	Harness, Wiring 40 Harness, Wiring - Remote 42 Head, Cylinder 4 Holder, Fuse 40 Housing, Air 30 Housing, Below Floor 36 Housing, Breather 4 Housing, Cleaner - Air 14,16 Housing, Cylinder - Air 30 Housing, Choke 14 Housing, Connector 40,42 Housing, Socket 40 Housing, Stator 38 Hose, Fuel 16 Hose, Preheater 14 Hose, Vacuum 14 Hub, Cup - Governor 8 Index, Numerical 44,45,46,47 Insert, Valve Seat 4 Insulator, Fuse 40 Insulator, Terminal - Start Solenoid 40 Isolator, Vibration 10 Joint, Ball 21 Key, Gear - Crankshaft 9 Key, Woodruff - Camshaft 8
Bushing 40 Cable, Plug - Spark 22 Camshaft 8 Cap, Fill - Oil 10 Cap, Insulating 28 Cap and Valve, Breather 6 Carburetor Components (Gasoline) 19,20 Carburetor Components (LP) 18 Carburetor, Gasoline 14 Carburetor, LP 16 Clamp, Coil 22 Clamp, Muffler 32,34 Clip, Cover - Breaker Box 23 Clip, Housing - Choke 14 Coil, Ignition 22 Condenser, Ignition 22,23 Connector, Parallel 28 Connector, Eight Pin 40 Connector, Receptacle 38 Connector, Tab 38 Control, Start - Remote 42 Cover, Block - Brush 38 Cover, Box - Breaker 23 Cover, Control 40 Cover, Housing - Choke 14 Cover, Transformer 38 Crankshaft 9	Harness, Wiring 40 Harness, Wiring - Remote 42 Head, Cylinder 4 Holder, Fuse 40 Housing, Air 30 Housing, Below Floor 36 Housing, Breather 4 Housing, Cleaner - Air 14,16 Housing, Cylinder - Air 30 Housing, Choke 14 Housing, Connector 40,42 Housing, Socket 40 Housing, Stator 38 Hose, Fuel 16 Hose, Preheater 14 Hose, Vacuum 14 Hub, Cup - Governor 8 Index, Numerical 44,45,46,47 Insert, Valve Seat 4 Insulator, Fuse 40 Insulator, Terminal - Start Solenoid 40 Isolator, Vibration 10 Joint, Ball 21 Key, Gear - Crankshaft 9 Key, Woodruff - Camshaft 8 Kit, Brush Repair - Starter 25
Cable, Plug - Spark 22 Camshaft 8 Cap, Fill - Oil 10 Cap, Insulating 28 Cap and Valve, Breather 6 Carburetor Components (Gasoline) 19,20 Carburetor Components (LP) 18 Carburetor, Gasoline 14 Carburetor, LP 16 Clamp, Coil 22 Clamp, Muffler 32,34 Clip, Cover - Breaker Box 23 Clip, Housing - Choke 14 Coil, Ignition 22 Condenser, Ignition 22,23 Connector, Parallel 28 Connector, Eight Pin 40 Connector, Receptacle 38 Connector, Tab 38 Control, Start - Remote 42 Cover, Block - Brush 38 Cover, Control 40 Cover, Housing - Choke 14 Cover, Housing - Choke 14 Cover, Transformer 38 Crankshaft 9 Cup, Governor 8 Cup, Intake - Oil Pump 10	Harness, Wiring 40 Harness, Wiring - Remote 42 Head, Cylinder 4 Holder, Fuse 40 Housing, Air 30 Housing, Below Floor 36 Housing, Breather 4 Housing, Cleaner - Air 14,16 Housing, Cylinder - Air 30 Housing, Connector 40,42 Housing, Connector 40,42 Housing, Socket 40 Housing, Stator 38 Hose, Fuel 16 Hose, Preheater 14 Hose, Vacuum 14 Hub, Cup - Governor 8 Index, Numerical 44,45,46,47 Insert, Valve Seat 4 Insulator, Fuse 40 Insulator, Terminal - Start Solenoid 40 Isolator, Vibration 10 Joint, Ball 21 Key, Gear - Crankshaft 9 Key, Woodruff - Camshaft 8 Kit, Brush Repair - Starter 25 Kit, Carburetor Repair 19,20
Bushing 40 Cable, Plug - Spark 22 Camshaft 8 Cap, Fill - Oil 10 Cap, Insulating 28 Cap and Valve, Breather 6 Carburetor Components (Gasoline) 19,20 Carburetor, Gasoline 14 Carburetor, LP 16 Clamp, Coil 22 Clamp, Muffler 32,34 Clip, Cover - Breaker Box 23 Clip, Housing - Choke 14 Coil, Ignition 22 Condenser, Ignition 22,23 Connector, Parallel 28 Connector, Eight Pin 40 Connector, Receptacle 38 Connector, Tab 38 Control, Start - Remote 42 Cover, Block - Brush 38 Cover, Box - Breaker 23 Cover, Control 40 Cover, Housing - Choke 14 Cover, Transformer 38 Crankshaft 9 Cup, Governor 8	Harness, Wiring 40 Harness, Wiring - Remote 42 Head, Cylinder 4 Holder, Fuse 40 Housing, Air 30 Housing, Below Floor 36 Housing, Breather 4 Housing, Cleaner - Air 14,16 Housing, Cylinder - Air 30 Housing, Connector 40,42 Housing, Connector 40,42 Housing, Socket 40 Housing, Stator 38 Hose, Fuel 16 Hose, Preheater 14 Hose, Vacuum 14 Hub, Cup - Governor 8 Index, Numerical 44,45,46,47 Insert, Valve Seat 4 Insulator, Fuse 40 Insulator, Terminal - Start Solenoid 40 Isolator, Vibration 10 Joint, Ball 21 Key, Gear - Crankshaft 9 Key, Woodruff - Camshaft 8 Kit, Brush Repair - Starter 25 Kit, Carburetor Repair 19,20
Cable, Plug - Spark 22 Camshaft 8 Cap, Fill - Oil 10 Cap, Insulating 28 Cap and Valve, Breather 6 Carburetor Components (Gasoline) 19,20 Carburetor, Components (LP) 18 Carburetor, LP 16 Clamp, Coil 22 Clamp, Muffler 32,34 Clip, Cover - Breaker Box 23 Clip, Housing - Choke 14 Coil, Ignition 22 Condenser, Ignition 22,23 Connector, Parallel 28 Connector, Eight Pin 40 Connector, Receptacle 38 Connector, Tab 38 Control, Start - Remote 42 Cover, Block - Brush 38 Cover, Box - Breaker 23 Cover, Control 40 Cover, Housing - Choke 14 Cover, Transformer 38 Crankshaft 9 Cup, Governor 8 Cup, Intake - Oil Pump 10 Decal (Emerald I) 40,43	Harness, Wiring 40 Harness, Wiring - Remote 42 Head, Cylinder 4 Holder, Fuse 40 Housing, Air 30 Housing, Below Floor 36 Housing, Breather 4 Housing, Cleaner - Air 14,16 Housing, Cylinder - Air 30 Housing, Connector 40,42 Housing, Connector 40,42 Housing, Socket 40 Housing, Sattor 38 Hose, Fuel 16 Hose, Preheater 14 Hose, Vacuum 14 Hub, Cup - Governor 8 Index, Numerical 44,45,46,47 Insert, Valve Seat 4 Insulator, Fuse 40 Insulator, Terminal - Start Solenoid 40 Isolator, Vibration 10 Joint, Ball 21 Key, Gear - Crankshaft 9 Key, Woodruff - Camshaft 8 Kit, Brush Repair - Starter 25 Kit, Carburetor Repair 19,20 Kit, Gasket - Engine 6
Bushing 40 Cable, Plug - Spark 22 Camshaft 8 Cap, Fill - Oil 10 Cap, Insulating 28 Cap and Valve, Breather 6 Carburetor Components (Gasoline) 19,20 Carburetor, Gasoline 14 Carburetor, LP 16 Clamp, Coil 22 Clamp, Muffler 32,34 Clip, Cover - Breaker Box 23 Clip, Housing - Choke 14 Coil, Ignition 22 Condenser, Ignition 22,23 Connector, Parallel 28 Connector, Eight Pin 40 Connector, Receptacle 38 Connector, Tab 38 Control, Start - Remote 42 Cover, Block - Brush 38 Cover, Box - Breaker 23 Cover, Control 40 Cover, Housing - Choke 14 Cover, Housing - Choke 14 Cover, Transformer 38 Crankshaft 9 Cup, Governor 8 Cup, Intake - Oil Pump 10 Decal (Emerald I) 40,43 Diode 42	Harness, Wiring 40 Harness, Wiring - Remote 42 Head, Cylinder 4 Holder, Fuse 40 Housing, Air 30 Housing, Below Floor 36 Housing, Breather 4 Housing, Cleaner - Air 14,16 Housing, Cylinder - Air 30 Housing, Connector 40,42 Housing, Connector 40,42 Housing, Socket 40 Housing, Stator 38 Hose, Fuel 16 Hose, Preheater 14 Hose, Vacuum 14 Hub, Cup - Governor 8 Index, Numerical 44,45,46,47 Insert, Valve Seat 4 Insulator, Fuse 40 Insulator, Terminal - Start Solenoid 40 Isolator, Vibration 10 Joint, Ball 21 Key, Gear - Crankshaft 9 Key, Woodruff - Camshaft 8 Kit, Brush Repair - Starter 25 Kit, Carburetor Repair 19,20
Cable, Plug - Spark 22 Camshaft 8 Cap, Fill - Oil 10 Cap, Insulating 28 Cap and Valve, Breather 6 Carburetor Components (Gasoline) 19,20 Carburetor, Components (LP) 18 Carburetor, LP 16 Clamp, Coil 22 Clamp, Muffler 32,34 Clip, Cover - Breaker Box 23 Clip, Housing - Choke 14 Coil, Ignition 22 Condenser, Ignition 22,23 Connector, Parallel 28 Connector, Eight Pin 40 Connector, Receptacle 38 Connector, Tab 38 Control, Start - Remote 42 Cover, Block - Brush 38 Cover, Box - Breaker 23 Cover, Control 40 Cover, Housing - Choke 14 Cover, Transformer 38 Crankshaft 9 Cup, Governor 8 Cup, Intake - Oil Pump 10 Decal (Emerald I) 40,43	Harness, Wiring 40 Harness, Wiring - Remote 42 Head, Cylinder 4 Holder, Fuse 40 Housing, Air 30 Housing, Below Floor 36 Housing, Breather 4 Housing, Cleaner - Air 14,16 Housing, Cylinder - Air 30 Housing, Connector 40,42 Housing, Connector 40,42 Housing, Socket 40 Housing, Sattor 38 Hose, Fuel 16 Hose, Preheater 14 Hose, Vacuum 14 Hub, Cup - Governor 8 Index, Numerical 44,45,46,47 Insert, Valve Seat 4 Insulator, Fuse 40 Insulator, Terminal - Start Solenoid 40 Isolator, Vibration 10 Joint, Ball 21 Key, Gear - Crankshaft 9 Key, Woodruff - Camshaft 8 Kit, Brush Repair - Starter 25 Kit, Carburetor Repair 19,20 Kit, Gasket - Engine 6

Index

Labels 43 Label, Preheat 14,43 Lead, Pressure Switch - Low Oil 12 Line, Fuel 14,16 Link, Spring - Governor 13 Lock, Spring - Valve 4 Manifold, Exhaust 16,32,34 Manifold, Intake 14,16 Meter, Condition - Battery 42 Meter, Totalizing - Time 42 Muffler, Arrestor - Spark 32,34 O-Ring, Housing - Stator 28	Seal, Oil - Crankshaft 4 Seal, Valve - Intake 4 Sealant, Thread 43 Scroll, Air 30 Shield, Noise 30 Shield, Noise 30 Shim, End - Crankshaft 4 Solenoid, Lock - Fuel 16 Solenoid, Start 40 Spacer, Bracket - Fuel Pump 14 Spacer, Muffler 32 Spring, Brush - Generator 38 Spring, Governor 21 Spring, Valve - Breather 4 Spring, Valve - Oil Bypass 6
Paint, Touch-Up - Enamel 43 Pan, Drip 10,36 Panel, Control 42 Panel, Housing 36 Pin, Alignment - Gearcover 4 Pin, Center - Camshaft 8 Pin, Contact 40,42 Pin, Hinge 36	Starter 24 Starter Components 25,26 Stator, Wound 38 Strap, Ground 10,30 Strap, Muffler 32 Support, Hinge 36 Support, Housing 36 Switch, Rocker 40,42
Pin, Piston 6 Pin, Drive - Bearing Stop 4 Piston 6 Plate, Bearing - Rear 4 Plate, Hinge 36 Plug, Button - Dot 30 Plug, Drain - Oil 10 Plug, Hole - Core 6 Plug, Spark 22 Plug, Welch - Camshaft 4	Tab, Terminal 40 Tappet, Valve 4 Terminal, Receptacle 28 Terminal, Ring 24,40 Transformer - Regulator 28 Tube, Exhaust 32,34 Tube, Housing - Choke 14 Tube, Oil - Cylinder Block 4 Valve, Intake and Exhaust 4
Plunger, Points - Breaker 23 Point, Breaker 23 Pump, Oil 6 Rectifier, Bridge 40 Rectifier, Silicon 40 Reed, Valve - Breather 4	Valve, Shut-Off - Fuel 16 Valve, Shut-Off - Oil Base 10 Yoke, Governor 13
Relay, Ignition 16 Regulator, LP Fuel 16 Resistor, Fixed 27 Ring, Collector - Armature 38 Ring, Retaining 8,9 Ring, Retaining - Piston Ring 6 Ring Set, Piston 6 Rod, Connecting 6 Rod, Governor to Carburetor 21 Rod, Inlet - Air 14	

Introduction

This catalog applies to the Standard BGE/BGEL Recreational Vehicle Generator Sets as listed in the Generator Set Data Table. Parts are arranged in groups of related items and each illustrated part is identified by a reference number corresponding to the same reference number in the parts list. Unless otherwise mentioned in the description, parts are interchangeable between models. Parts illustrations are typical. Using the model and specification number from your generator set nameplate, select parts that apply to your set. Right and Left sides are determined by Facing the engine (front) of the set.


Generator Set Data Table

MODEL AND	ELECTRICAL DATA								
SPECIFICATION	WATTS	VOLTS	HERTZ	WIRE	PHASE	FUEL			
3.5 BGEL-53CR* 3.5 BGE-53BR* 3.5 BGE-53CR* 4.0 BGE-1R/* 4.0 BGEL-1R/* 4.0 BGEL-7A/* 4.0 BGE-7A/*	3500 3500 3500 4000 4000 4000	120/240 110/220 120/240 120 120 120 120/240	50 50 50 60 60 60	3 3 3 2 2 2	1 1 1 1 1	LP-Liquid Gasoline Gasoline Gasoline LP-Liquid Gasoline Gasoline			

* - The diagonal line (/) in the model and specification number separates generator set characteristics from the specification number and letters. The specification number denotes customer requested options or deviations from a standard (1A, 1B, etc.) model. The specification letter advances (A, to 8, to C, etc.) with major manufacturing changes.

NOTE:

Components Sold As An Assembly Will Be Assembled At The Factory.



	Cylinder Block 566 560 560									
REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART 5600-00: DESCRIPTION 5620-00: 5620-01:	03 30		
1		1	Block, Cylinder (See Short	25	123-1649	1	Housing, Breather 5620-01	31		
			Block Catalog #932-0109)	26	110-3709	3	Gasket, Cover – Valve			
			(Includes Parts Marked *)	27			Tappet, Valve			
2	517-0048	1	*Plug, Welch - Camshaft		115-0006	4	Standard			
			Opening (1-5/8")		115-0006-02	4	.002" Oversize			
3			*Screw, Cap - Hex Head		115-0006-05	4	.005" Oversize			
	800-0051	5	3/8-16 × 1-1/4"	28			Valve, Intake			
	800-0575	5	3/8-16 x 1-1/8" - Flanged		110-1808	2	Spec A-C			
			Head - BGEL Spec D		110-3479	2	Begin Spec D			
4	104-0776	AR	*Shim, End - Crankshaft	29			Valve, Exhaust			
			Play (.005")		110-1955	2	Spec A-C			
5			Bearing, Crankshaft - Rear		110-3480	2	Stellite - Begin Spec D			
			(Includes Thrust Washer)		110-3515	2	Standard - Begin Spec D			
	101-0450	1	* Standard	30	800-0010	2	Screw, Cap - Hex Head			
	101-0450-02	1	.002" Undersize				$(1/4-20 \times 1-3/4")$			
	101-0450-10	ī	.010" Undersize	31			Spring, Valve			
	101-0450-20	ī	.020" Undersize		110~0539	4	Used on BGE Spec A-C and			
	101-0450-30	ī	.030" Undersize				BGEL Spec B			
6	104-0575	2	*Washer, Thrust (Special)		110-3485	4	Begin Spec D			
7	101-0782	ī	*Gasket, Plate - Bearing	32			Lock, Spring - Valve			
8	101-0439	1	*Plate, Bearing - Rear		110-0639	8	Used on BGE Spec A-C and			
9	101-0405	2	*Bearing, Camshaft				BGEL Spec B			
10	509-0041	ī	Seal, Oil - Crankshaft Rear		110-3511	8	Begin Spec D			
11	516-0072	4	*Pin, Drive - Bearing Stop	33			Seal, Valve - Intake			
12	120-0735	i	*Tube, Oil - Cylinder Block		110-3604	2	Used on BGE Spec A-C and			
13	120 0.00	-	Insert, Valve Seat - Exhaust				BGEL Spec B			
10	110-1824	2	* Standard		509-0210	2	Begin Spec D			
	110-1824-02	2	.002" Oversize	34	803-0071	2	Screw, Socket - Set			
	110-1824-05	2	.005" Oversize			_	$(3/8-16 \times 5/8")$			
	110-1824-10	2	.010" Oversize	35	123-1417	1	Filter, Breather			
	110-1824-25	2	.025" Oversize	36	110-3181	2	Gasket, Head - Cylinder			
14	110 1024 20	~	Insert, Valve Seat - Intake	37	114 0101	_	Head, Cylinder			
1-	110-0197	2	* Standard				Used on BGE Spec A-C and			
	110-0197-02	2	.002" Oversize				BGEL Spec B			
	110-0197-05	2	.005" Oversize		110-3214	1	Right Side			
	110-0197-03	2	.010" Oversize		110-3213	1	Left Side			
	110-0191-10	4	.UIU UVEFS1ZE		110-3213	1	Leit Side			

110-3509

110-3508

110-0893

110-3487

526-0018

526-0122

800-0540

800-0571

800-0572

800-0571

38

39

40

41

1

2

4

1

8

8

10

10

18

.025" Oversize

.002" Undersize

.020" Undersize

.030" Undersize

(Flanged)

Standard

*Guide, Valve

Spec A-C

*Washer

Bearing, Crankshaft - Front

Exhaust - Begin Spec D Intake - Begin Spec D

*Pin, Alignment - Gear Cover

Lock (3/8") Flat (3/8" Screw) -

Reed, Valve - Breather

Baffle, Valve - Breather Spring, Valve - Breather Cover, Valve - RH

BGEL Spec D

110-0197-25

101-0432-02

101-0432-10

101-0432-20

101-0432-30

110-3527

110-3526

110-1935

850-0050

526-0251

123-1175

123-1174 110-1879-01

20 516-0141

22 123-1173

1

1

1

1

1

2

2

4

5

5

2

1

1

1

1

101-0432

15

16

19

21

23

24

Begin Spec D

(Optional)

(Special)

Right Side

Left Side

BGEL Spec B

BGEL Spec B 1-5/8" Long

2" Long

2" Long

Begin Spec D

2-3/8" Long

Washer, Flat (1/4") Washer, Flat (5/16") Screw, Cap - Hex Head


Begin Spec D

Retainer, Spring - Valve

Used on BGE Spec A-C and

Used on BGE Spec A-C and


5600-0001 5600-0002 5600-0004 5600-0011



Cylinder Block

5600-0001 5600-0002


	Cylinder Block										
REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION	5600-0054 5600-0055 5600-0056			
42	526-0063	2	Washer, Flat - Copper (1/4")	55	112-0229	2	Pin, Piston	5620-0003 5620-0130			
43	517-0067	1	Plug, Hole	56	518-0311	4	Ring, Retaining	5620-0131			
44	110-3510	4	Cap, Valve (Begin Spec D)	57			Ring Set, Piston				
45	110 0010	•	Gasket Kit		113-0189	2	Standard				
. •	168-0178	1	Carbon Removal/Valve Grind		113-0189-05	2	.005" Oversize				
	168-0181	$\bar{1}$	Engine, Complete		113-0189-10	2	.010" Oversize				
46	120-0491	ī	Pump, Oil (Components Not		113-0189-20	2	.020" Oversize				
			Sold Separately)		113-0189-30	2	.030" Oversize				
47	120-0161	1	Gasket Kit, Pump - Oil		113-0189-40	2	.040" Oversize				
48	740-1004	2	Washer, Flat (M6)	58			Rod, Connecting				
49	800-0007	2	Screw, Cap - Hex Head				(Includes Bolt And Nut)				
			$(1/4-20 \times 1")$		114-0257	2	Standard				
50			Screw, Cap - Hex Head		114-0257-10	2	.010" Undersize				
	801-0050	1	$3/8-24 \times 1$ " - Used on BGE		114-0257-20	2	.020" Undersize				
			Spec A-C and BGEL Spec B		114-0257-30	2	.030" Undersize				
	801-0049	1	$3/8-24 \times 7/8"$ - Begin Spec D	59	114-0240	4	Bolt, Connecting Rod				
51	526-0066	1	Washer, Flat - Copper (3/8")				(Special)				
52	120-0140	1	Spring, Valve - Bypass	60	870-0302	4	Nut, Self-Locking (5/16-	24)			
53	120-0398	1	Plunger, Valve - Bypass	61	110-0904	4	Cap, Roto Valve - Exhaus				
54			Piston (Includes Pin and				(Used on BGE Spec A-C a	nd			
			Retaining Rings)				BGEL Spec B)				
	112-0186	2	Standard								
	112-0186-05	2	.005" Oversize								
	112-0186-10	2	.010" Oversize	* _	Parts Includ	led in	Cylinder Block.				
	112-0186-20	2	.020" Oversize								
	112-0186-30	2	.030" Oversize								
	112-0186-40	2	.040" Oversize								



C-1084

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	150-0078	1	Ring, Retaining	7	105-0332	1	Gear, Camshaft
2	150-1519	1	Hub, Cup - Governor				(Includes Gear, Spacer
3	150-1520	1	Cup And Bushing, Governor				And Plate)
4	510-0015	10	Ball, Governor	8	105-0541	1	Washer, Thrust - Special
5	515-0001	1	Key, Woodruff	9	150-0075	1	Pin, Center - Camshaft
6	105-0637	1	Camshaft (Includes Center Pin)				


Crankshaft And Flywheel



CT-1084

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	RE! NO		QTY USED	PART DESCRIPTION
1	104-0170	1	Screw, Cap ~ Hex Head (Special)	6 7	104-0043 104-0032		asher,Gear ear, Crankshaft
2	526-0356	1	Washer, Flat (7/16" Screw)	8	515-0263	1 * K€	ey Kit, Wheel - Blower
3	526-0017	1	Washer, Flat (7/16")	9	515-0001	1 * K€	ey, Gear - Crankshaft
4	134-4342	1	Flywheel, (Blower)	10	104-1583	1 Cr	rankshaft (Includes Parts
5	518-0014	1	Ring, Retaining			1	Marked *)


^{* -} Parts Included In 104-1583 Crankshaft Kit.



Oil Base And Mounting Hardware


5620-0063


REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.		QTY USED	PART DESCRIPTION
1	102-1286	1	Base, Oil	13	337-2311	1	Strap, Ground (Mounts Scroll
2 3	102-1387	1	Gasket, Base ~ Oil Pan, Drip	14		1	To Drip Pan) Screw, Hex Washer Head - Self
-	403-2218	1	Above Floor Models				Locking
	403-2280	1	Below Floor Models		821-0014	1	BGE $(5/16-18 \times 1/2")$
4			Isolator, Vibration -		821-0029	1	BGEL $(3/8-16 \times 3/4")$
			Generator End	15	856~0008	2	Washer, Lock EIT (5/16")
	402-0597	2	Voltage Code FA - Spec C,D,E	16	123-1616	1	Cup, Intake - Oil Pump
	402-0602	2	Voltage Code FJ - Spec C & E				(Includes Pipe And Cup)
4A	402-0547	2	Snubber (Use with Isolator 402-0597)	17	504-0150	1	Valve, Shut-Off - Oil Base Rear Drain (Above Floor
5	821-0010	4	Screw, Hex Washer Head -				Model)
			Self-Locking $(1/4-20 \times 1/2")$	18	800~0058	4	Screw, Cap - Hex Head
	526-0325	2	Washer, Flat (3/8")				(3/8-16 × 3")
7	815-0657	2	Screw, Hex Head - Thread		850-0050	4	Washer, Lock (3/8")
			Form $(3/8-16 \times 2-3/4")$		123-1625	1	Cap, Fill ~ Oil
8	402-0549	1	Isolator, Vibration - Engine	21	509-0096	1	O-Ring, Cap - Oil Fill
			End	22			Plug, Drain - Oil
9	821-0016	2	Screw, Hex Washer Head - Self Locking (5/16-18 x 3/4")		102-0938	1	Rear Drain, Bottom Drain Oil Base (1/2")
10	821-0031	2	Screw, Hex Washer Head - Self Locking (3/8-16 x 3/4")		505-0110	1	Square Head, Bottom Drain Oil Base (3/8")
11	526-0324	1	Washer, Flat (5/16")		505-0266	1	Square Head, Countersunk
12	526-0240	1	Washer, Flat (3/8")	23	102-0743	1	(3/8" Pipe) - Bottom Drain Gasket, Plug - Oil Drain



REF	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	122-0320 526-0065	1 2	Adapter, Oil Filter Washer, Flat - Copper	5	815-0194	2	Screw, Cap - Hex Head W/ET (#10-32 x 3/8")
_	020 0000	_	(5/16" Screw)	6	122-0774	1	Gasket, Oil Filter Adapter
3	800-0028	2	Screw, Cap - Hex Head	7	122-0645	1	Filter, Oil Switch, Low Oil Pressure
			$(5/16-18 \times 1")$	_	309-0322 226-2980	1	Lead, Low Oil Pressure Switch
4			Drain, Oil Filter	9	220-2900	1	Lead, Low off freedom of our con-
	122-0360	1	Unpainted				
	122-0360-50	1	Painted				

Gearcase 5620-0046






FS-1596

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	103-0772	1	Gearcase (Kit)	10	103-0810	1	Gasket, Mounting - Gearcase
_		_	(Includes Parts Marked*)	11	526-0065	5	Washer, Flat - Copper (5/16")
2	150-2002	1	*Arm And Shaft, Governor	12			Screw, Cap - Hex Head
3	509-0008	1	*Seal, Oil - Governor Shaft				(Special)
4	510-0013	1	*Bearing, Needle		114-0022	4	1-3/4" Long
5	510-0014	1	*Ball, Bearing		800-0545	1	2-3/4" Long
6	516-0130	1	*Pin, Dowel - Governor Cup	13	150-1998	1	*Link, Spring - Governor
			Stop	14	870-0328	1	*Nut, Self-Lock (#10-32")
7	150-1187	1	*Yoke, Governor	15	141-0710	1	*Spring, Idle Needle
8	815-0046	2	*Screw, Machine - Pan Head (#8-32 x 3/8")	16	820-1077	1	*Screw, Pan Head (#10-32 x 2-1/2")
9	509-0040	1	*Seal Oil - Crankshaft				


^{* -} Parts Included In 103-0772 Gearcase.



Fuel System (Gasoline)

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	154-2447	1	Manifold, Intake	26	503-1252	1	Hose, Vacuum
2	815-0587	2	Screw, Hex Washer Head (Special)	27	502-0871	1	(3/16" ID x 3" Long) Fitting, Vacuum - Intake 90*
3	141-0950	1	Gasket, Mounting - Carburetor	21	302 0011	**	Manifold To Vacuum Hose
4	862-0015	ī	Nut, Hex (5/16-18)	28	502-0313	1	Elbow, 90°
5	146-0455	1	Carburetor (Includes Mounting Gasket) (See Separate Page for Components)	29 30	332-2431	1	Terminal, Lead - Fuel Pump (.225") Line, Fuel (Includes 2
6	502-0002	2	Elbow, Male - Inverted	•			Inverted Nuts)
7	153-0555	ī	Element And Cover, Choke		149-2084	1	Used With Fuel Pump 149-2110
8	140-1087	1	Gasket, Horn - Air		149-1929	1	Use With Fuel Pump 149-1994
9	815-0590	3	Screw, Hex Head (Special)	31	98-5335	1	Label, Preheat
10	153-0556	1	Housing Assembly, Choke (Includes Parts Marked *)	32	332-2572	1	Terminal, Lead - Fuel Pump (.250 Recep)
	153-0563	1	*Housing, Choke	33	154-2495	2	Gasket, Manifold - Intake
	153-0571	1	*Washer, Insulating - Choke	34	800-0033	4	Screw, Cap - Hex Head
	518-0387	1	*Ring, Retainer				$(5/16-18 \times 2")$
	153-0567	1	*Shaft Assembly, Housing -	35		4	Washer, Lock - Spring (5/16")
			Choke		503-1345	2	Clamp, Hose
11	815-0592	2	Screw, Hex Washer Head	37	140-1919	1	Adapter, Preheater
			(Special)		123-1615	1	Tube, Breather
12	153-0561	1	Bracket, Mounting - Diaphragm	40		1	Clamp, Hose - Breather Tube
13	518-0450	1	Clip, U - Diaphragm Mounting Bracket	41	503-0183	1	Clamp, Hose - Breather Tube Fits Hose O.D. 1-1/32"
14	149-1994	1	Pump, Fuel - Electric Used Prior To: Generator	42	815-0261	2	Screw, Hex Washer Head - Thd. Cutting (1/4-20 x 1/2")
			Set Serial Number	43	153-0578	1	Tube, Housing - Choke
			F860825839 Generator Set	44	517-0223	1	Cap, Vinyl
			S/N F863114065 (Not	45	526-0002	1	Washer, Flat (#6)
			Interchangeable with	46	120-0140	1	Spring, By-pass
			149-2110)	47	145-0562	1	Rod, Inlet - Air
	149-2110	1	Begin: Generator Set Serial	48	145-0561	1	Cover, Inlet - Air
			Number F860825893 (During	49	503-1351	1	Hose, Preheater
			Spec C) Generator S/N	50	153-0579	1	Cover, Housing - Choke
			F863114065	51	870-0421	1	Nut, Cap (#6-32)
15	153-0554	1	Bi-Metal, Choke	52	518-0466	1	Clip, Housing - Choke
16	153-0557	1	Bracket, Mounting - Housing	53	518-0459	1	Clip, Hose - Preheater
17	815-0591	2	Screw, Hex Washer Head (Special)	54	134-2100	1	Spacer, Bracket - Fuel Pump (Use With Fuel Pump 149-2110)
18	800-0017	1	Screw, Cap - Hex Head (1/4-20 x 3-1/2")	55	149-2082	1	Bracket, Pump - Fuel (Use With Fuel Pump 149-2110)
19	526-0018	1	Washer, Flat (1/4" Screw)	56	821-0009	1	Screw, Hex Washer Head -
20	140-1891	1	Element, Cleaner - Air				Self-Lock $(1/4-20 \times 3/8")$
21	140-1894	ī	Housing, Cleaner - Air	5 7	856-0006	1	Washer, Lock - EIT (1/4")
22	153-0558	1	Linkage, Choke	58	815-0610	1	Screw, Hex Washer Head -
23	140-1889	ī	Adapter, Cleaner - Air				Thread Form $(1/4-20 \times 1")$
24	153-0577	1	Linkage, Pull-off	59	815-0261	1	Screw, Hex Washer Head -
25	153-0576	1	Pull-off, Choke				Thread Cutting $(1/4-20 \times 1/2")$


Fuel System (LP)



Fuel System (LP)


REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	154-2447	1	Manifold, Intake	30	502-0932-01	1	Elbow, Street - 45°
2	815-0587	2	Screw, Hex Washer Head (Special)	•	302 3002 32	_	(Front Outlet, Exhaust Manifold)
3	141-0281	1	Gasket, Mounting - Carburetor	31			Elbow, Male ~ 90°
4	862-0015	2	Nut, Hex (5/16-18)		502-0933-01	1	Front Outlet, Exhaust
5	141-0932	1	Carburetor (See Separate Page				Manifold
-			For Components)		502-0054	1	Bottom Outlet, Exhaust
6	505-0274	1	Plug, Pipe - Hex (1/8")			_	Manifold
7	307-1886	1	Relay, Ignition	32	307-2478	1	Solenoid, Lock - Fuel (Front
8	140-2308	1	Gasket, Horn - Air		454 4545	_	Outlet - Exhaust Manifold)
9	815-0590	3	Screw, Cap - Hex Head	33	154-2745	2	Gasket, Manifold - Intake
			(Special)	34	502-0928-01	1	Adapter, Reducer - Front Outlet - Exhaust Manifold
10	526-0008	1	Washer, Flat (#10)	25	501-0525	1	Line, Fuel
11	015 0501	4	Screw, Hex Washer Head	35	336-9679	1	Lead, Bracket - Filter Mounting
	815-0531	1 1	Special (Spec B) #10-32 x 1/2" (Spec D)	37	815-0261	2	Screw, Hex Washer Head
10	821-0005 503-0183	2	Clamp, Hose (9/16 to	31	013 0201	2	$(1/4-20 \times 1/2")$
12	503-0163	2	1-1/16")	38	154-2627	1	Manifold, Exhaust
13	503~1365	1	Hose, Fuel (7-1/2" Long)	00	104 2021	•	(Includes Heat Shield And
14	148-0893	1	Regulator				Fuel Line)
15	502-0927-01	ī	Bushing, Reducer (3/8 x 1/4")	39	502-0965-01	1	Elbow, Reducing - 45*
16	502 0527 01	-	Bracket, Mounting - Housing	•		_	(Bottom Outlet, Exhaust
	153-0557	1	Spec B				Manifold)
	307-2559-01	ĩ	Spec D - Zinc Plated	40	502-0929-01	1	Nipple, Close (Bottom
17	815-0591	2	Screw, Hex Washer Head				Outlet, Exhaust Manifold)
			(Special)	41	307-2501	1	Valve, Fuel Shut-off
18	800-0017	1	Screw, Cap - Hex Head (1/4-20 x 3-1/2")				(Bottom Outlet, Exhaust Manifold)
19	526-0018	1	Washer, Flat (1/4" Screw)	42	815-0176	1	Screw, Hex Head - Machine
20	140-1891	1	Element, Cleaner - Air				$\#(8-32 \times 1/2")$
21	140-1894	1	Housing, Cleaner - Air		870-0221	1	Nut, Hex (#8-32)
22	502-0838	1	Elbow, Reducing - 90°		503-1190	1	Clamp, Hose
23	140-1889	1	Adapter, Cleaner - Air		526-0003	1	Washer, Flat (#8)
24	815-0647	2	Screw, Hex Washer Head		148-0898	1	Element, Filter - Fuel
			$(1/4-20 \times 5/8")$	47	800-0033	4	Screw, Cap - Hex Head
25	850-0040	2	Washer, Lock (1/4")	40	E40 1000		$(5/16-18 \times 2")$
26	502-0935	1	Elbow, 90°	48	740-1006	4	Washer, Flat (M8)
27			Bracket, Mounting - Filter	49		1	Tube, Breather
	148-0896	1	Bottom Outlet Exhaust	50	503-0183	1	Clamp, Hose - Breather Tube (1.13" Dia.)
	148-0903	1	Front Outlet Exhaust	E 1	E02_1122	1	Clamp, Hose - Breather
28	148-0890	1	Filter, LPG (Includes Element And O-Rings)	51	503-1133		Tube (.900" Dia.)
29			Screw, Cap - Hex Head - Thread		148-0897	1	Washer, Mounting - Regulator
			Form $(1/4-20 \times 1/2")$	53	149-2032-01	1	Bracket, Fuel Line - LP -
	815-0370	1	Spec B				Zinc Plated
	815-0261	2	Spec D				

Carburetor Components (LP)



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
	141-0932	1	Carburetor, Complete	9	141-0711	1	Spring, Stop - Throttle
1	141-0708	1	Bowl, Fuel	10	141-0736	1	Plug, Bowl
2	141-0698	2	Screw, Round Head	11	141-0077	1	Washer, Plug - Bowl
_			With Washer	12	141-0934	1	Needle, Adjust - Idle
3	141-0919	1	Plate, Throttle	13	141-0936	1	Lever, Shaft ~ Throttle
4	141-0940	$\bar{1}$	Seal, Dust	14	141-0939	1	Spring, Screw - Main Jet
5	141-0935	1	Spring, Needle - Idle	15	141-0937	1	Needle, Adjust - Idle
6	141-0938	1	Tube, Idle (Rubber)	16	141-0924	1	Seal, Rubber
7	141-0701	1	Gasket, Bowl	17	141-0281	1	Gasket, Flange - Carburetor
8	141-0700	1	Screw, Stop - Throttle				


Carburetor Components (Gasoline) Facet (Spec A-C)




REF NO.	PART NO.	QTY PART USED DESCRIPTION		PART NO.	QTY USEC	PART DESCRIPTION
	146-0455	Carburetor, Complete		1-0711	1	Spring, Stop - Throttle
		Gasoline - Electric Choke	14 14	1-0713	1	*Needle, Adjusting - Idle
1	141~0708	1 Bowl, Fuel	15 14	1-0710	1	Spring, Needle - Idle Adjusting
2	141-0741	1 Plate, Choke	16 14	1-0077	1	#*Washer, Jet - Main
3	141-0698	4 Screw, Round Head	17 14	1-0942	1	Jet, Main (Adjustable)
		With Washer				(Includes Packing)
4	141~0919	1 Plate, Throttle	18 14	1-0921	1	Shaft, Choke
6	141-0924	1 #*Seal, Rubber	19 14	1-0799	į.	*Spring, Fuel Float
7	141~0923	<pre>1 #*Seal Assembly, Valve</pre>	20 14	1-0281	1	#*Gasket, Flange - Carburetor
8	141-0920	1 Shaft, Throttle	21			Kit
9	141-0703	<pre>1 *Shaft, Float Pivot</pre>	14	1-0927	1	Repair, Carburetor
10	141-0702	1 Float, Carburetor				(Includes Parts Marked*)
11	141-0701	1 #*Gasket, Bowl	14	1-0928	1	Gasket, Carburetor
12	141-0700	1 Screw, Throttle Stop				(Includes Parts Marked#)

^{* -} Included In Repair Kit 141-0927. # - Included In Gasket Kit 141-0928.


Carburetor Components (Gasoline) Nikki (Spec C-F)




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
	146-0455	1	Carburetor, Complete (Includes Mounting Gaskets)	3 5	141-0281 146-0449	1	Gasket, Mounting - Carburetor Jet, Idle
1	146-0453	1	Float Kit, Carburetor (Includes Float, Pin and Valve)	6 7	146-0450 140-1087	1 1	Jet, Power Gasket, Horn - Air
2	146-0457	1	Repair Kit, Carburetor (Includes Gasket Package, Float Valve, Idle Adjust Needle And Spring, Mounting Gaskets, Adjust Limit Caps, Throttle Stop Screw And Spring)				



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REI NO		PART NO.	QTY USED	PART DESCRIPTION
1	870-0131	2	Nut, Hex - Self-Locking (10-32)	5 6		3-0006	1	Clip, Retaining Rod, Governor Arm To Carburetor
2	150-0096	1	Stud, Speed Adjustment		150	0-1957	1	BGE
3	150-1612	1	Spring, Governor		150	0-2102	1	BGEL
4	150-1958-02	1	Bracket, Governor - Zinc Plated	7	150	0-0939	1	Joint, Ball






REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
	160-1325	1	Box, Breaker	6	850-0038	2	*Washer, Lock - Spring (1/4")
			Complete (Includes Parts	7	160-1183	1	*Point, Breaker
			Marked *)	8	160-1314	1	*Base, Box - Breaker
1	160-1317	1	*Clip, Cover - Breaker Box	9	160-1150	1	*Gasket, Box - Breaker
2	160-1316	1	*Cover, Box - Breaker	10	336-2378	1	Lead, Breaker Box To Coil
_	815-0358	1	*Screw, Hex Head - Slotted Thread Form (#8-32 x 5/16")	11	160-1328	1	Tune-up Kit, Ignition (Includes Points And
4	312-0246	1	*Condenser, Ignition				Condenser)
5	802-0034	2	*Screw, Cap - Socket Head (1/4-20 x 3/4")	12	160-1151	1	Plunger, Points - Breaker


^{* -} Parts Included In 160-1325 Breaker Box.

Starter



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF No.	PART NO.	QTY USED	PART DESCRIPTION
1			Starter, 12 Volt (See Separate Page For Components)	6	850-0040	1	Washer, Lock (1/4") 4.0 BGE, BGEL
	191-1599	1	Spec A	7	862-0001	1	Nut, Hex (1/4-20)
	191-1667	1	Begin Spec B				4.0 BGE, BGEL
2	226-2426	1	Lead, Starter (Used on BGE Spec E and BGEL Spec D)	8	332-2748	1	Terminal, Ring (1/4") (Used on BGE Spec A-C and BGEL
3	800-0052	2	Screw, Hex Head - Cap				Spec B)
			$(3/8-16 \times 1-1/2")$	9	862-0003	2	Nut, Hex (3/8-16)
4	850-0050	2	Washer, Lock (3/8")				• • •

Starter Components - Spec A




REF	PART	QTY	PART	REF	PART	QTY	PART
NO.	NO.	USED	DESCRIPTION	NO.	NO.	USE	DESCRIPTION
1	191-1599	1	Motor, Starter (Complete)	20	NFS	2	+*Brush, Ground
2	815-0570	2	Screw, Cap - Hex Washer Head	21	NFS	1	+*Stud And Brush, Input
Inp	ut		(Special)	22	NFS	1	+Bushing, Insulation -
6	NFS	1	#Cover, Dust				Input Stud
7	NFS	1	#Nut, Stop	23	NFS	1	+Washer, Insulation -
8	NFS	1	#Washer, Stop Nut				Input Stud
9	NFS	1	#Spring, Anti-drift	24	NFS	1	+Washer, Flat - Input Stud
10	NFS	1	#Spacer, Dust Cover	25	NFS	1	+Washer, Lock - Input Stud
11	191-1156	1	Drive	26	NFS	1	+Nut, Securing - Input Stud
12	191-1048	2	Screw, Cap - Hex Head(Special)	27	191-1040	1	Cap, Commutator
13	850-0040	2	Washer, Lock (1/4")			_	(Includes Parts Marked +)
14	191-1633	ī	Cap, Drive End	28	NFS	1	Housing, Motor - Starter
15	191-1038	ī	Washer, Armature Thrust	29	191-1359	ī	Cover, Dust (Includes
16	191-1039	1	Armature			_	Parts Marked #)
17	NFS	4	+*Spring, Brush	30	191-1041	1	Repair Kit, Brush - Spring
18	NFS	1	+Holder, Brush			-	And Stud (Includes Parts
19	NFS	2	+Screw And Lockwasher				Marked *)

^{+ -} Included In The 191-1040 Cap.


* - Included In The 191-1041 Brush, Spring And Stud Kit.

- Included In The 191-1359 Dust Cover.

Starter Components (Begin Spec B)




REF	PART	QTY	PART	REF	PART	QTY	PART
NO.	NO.	USED	DESCRIPTION	NO.	NO.	USED	DESCRIPTION
1 2 3 4 5	191-1667 191-1817 191-1818 191-1785 191-1784 191-1781	1 1 1 1 1	Motor, Starter (Complete) Cover, Spring Retainer, Clutch Washer, Drive Clutch And Spline Cap, End	7 8 9	191-1776 191-1819 191-1786 191-1822 191-1820 191-1821	1 1 1 1 1	Cap, Drive End Gear, Starter Pin, Roll Washer, Pinion Spring, Pinion Retainer, Spring




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF No.	PART NO.	QTY USED	PART DESCRIPTION
1	870-0196	1	Nut, Insulation (#8)	10	332-0942	2	Tie, Cable
_		4			815-0340	1	Screw, Hex Washer Head
2	304-0015	1	Washer, Centering	11	015-0540	_	Thread Form (10-32 × 3/8")
3	304-0044	1	Resistor, Fixed - 2.5 Ohms				
			50 Watts	12	304-0772	1	Bracket, Mounting - Resistor
4	304-0773	1	Bracket, Mounting - Resistor				Forming $(1/4-20 \times 1/2")$
	815-0583	1	Screw, Cap - Hex Head	13			Screw, Hex Washer Head -
	010 0000	•	(Special)				Thread Cutting $(1/4-20 \times$
6	812-0061	2	Screw, Round Head				1/2")
•	012 0001	_	(#6-32 × 3/8")		815-0370	1	Used on BGE Spec A-C and
7	870-1183	2	Nut, Hex (Special)				BGEL Spec B
8	226-2754	1	Lead, 7" Long		815-0261	1	Used on BGE Spec E and
-		1	Lead, 3" Long				BGEL Spec D
9	226-2753	1	Leau, a Long				

Transformer Regulator



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1			Transformer-Regulator		337-2229	1	Bar, Bus (4-1/4" Long)
	315-0605	1	60 Hertz - 120 Volt 50 Hertz	11	815-0194	2	Screw, Cap - Hex Head (10-32 × 3/8")
	315-0645	1	110/220 Volt	12			Tie, Cable
	315-0646	ī	120/240 Volt (BGE Spec A-C		332-0941	1	60 Hertz
	010 0040	-	and BGEL Spec B Only)		332-0941	2	50 Hertz
2			Screw, Hex Washer Head -	13			Screw, Cap - Hex Head
-			Thread Form		815-0235	2	BGE (Spec A-C Only)
	815-0337	3	BGE $(1/4-20 \times 3/4")$				60 Hertz (1/4-20 x 5/8")
	815-0290	2	BGEL $(1/4-20 \times 5/8")$		815-0610	2	BGE, BGEL - 50 Hertz
3		_	Connector, Parallel				$(1/4-20 \times 1")$ - Also BGEL
-	332-0418	2	60 Hertz				60 Hertz
	332-0418	2 3	50 Hertz	14	509-0196	1	O-Ring, Stator Housing
5	331-0009	1	Connector $(3/4" \times 90")$	15	526-0018	2	Washer, Flat (1/4" Screw)
6	332-1993	2	Terminal, Receptable (1/4") (Spec A-C Only)	16	870-0433-03	2	Nut, Push-on (1/4-20)
7	856-0008	2	Washer, Lock - EIT (5/16")				
8	332-0046	2 2	Terminal, Ring (5/16")	* _	Parts Includ	led In	Transformer-Regulator.
			(Spec A-C Only)				
9			Cap, Insulating				
			60 Hertz				
	332-2699	3	4.0 BGE/BGEL (Spec A-C)				
			50 Hertz				
	898-1193-03	6	3.5 BGE (Spec A-C)				
	898-1193-03	3	3.5 BGE (Spec E)				


This Page is Blank



Air Housing

							5620-0128
REF No.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1			Screw, Hex Washer Head	6	134-4353	1	Housing, Cylinder Air - Left
			Self-locking	7	134-4352	1	Housing, Cylinder Air - Right
	821-0009	11	$1/4-20 \times 3/8$ " (Used on BGE	8	134-4348	1	Guard, Scroll
			Spec A-C and BGEL Spec B)	9	155-2040	1	Shield, Noise (BGE Sets Only)
	821-0010	2	$1/4-20 \times 1/2$ " (Used on BGE	10	856-0010	2	Washer, Lock (EIT - 3/8")
			Spec E and BGEL Spec D)	11	337-2311	1	Strap, Ground (Mounts Scroll
2	134-4463	1	Scroll (Includes Baffle)				To Drip Pan)
3			Screw, Hex Washer Head - Self-locking	12	517-0283	1	Plug, Dot Button - Use With Above Floor Models - Scroll
	821-0014	2	3.5 BGE (Spec A-C)				134-4345
			(5/16-18 × 1/2")	13	800-0048	1	Screw, Cap ~ Hex Head
	821-0016	2	4.0 BGE/BGEL $(5/16-18 \times 3/4")$				$(3/8-16 \times 3/4")$
4	134-4354	1	Backplate, Scroll	14	403-1523	2	Bracket, Lifting (Used on BGE
5	815-0261	4	Screw, Hex Head - Tapping Cylinder Air Housing (Right Hand) (1/4-20 x 1/2")				Spec A-C and BĞEL Spec B Only)

5620-0067




Exhaust System - Above Floor Models

							5620-0127
REF	PART	QTY	PART	REF	PART	QTY	PART
NO.	NO.	USED	DESCRIPTION	NO.	NO.	USED	DESCRIPTION
1	154-2462	1	Manifold, Exhaust - Bottom	12A	155-1485	1	Muffler, Arrestor - Spark
			Outlet (Spec A)				(Same End Inlet, Outlet)
1A	154-2551	1	Manifold, Exhaust - BGE		155-1239	1	Clamp, Muffler
			(Begin Spec B)		155-2174	1	Hanger, Exhaust
1B	154-2627	1	Manifold, Exhaust - BGEL		155-1015	1	Clamp, Muffler
			(Begin Spec B)	16			Screw, Hex Washer Head -
2	850-0045	7	Washer, Lock (5/16")				Thread Form
3	155-2049	1	Bracket, Exhaust (Begin Spec		815-0499	2	1/4-20 × 5/8"
			B)		815-0261	2	1/4-20 × 1/2"
4			Gasket, Exhaust	17		1	Strap, Muffler
	154-2061	1	Spec A		154-2746	2	Gasket, Exhaust Manifold
	154-2542	1	Begin Spec B	19	800-0026	4	Screw, Cap - Hex Head
5			Adapter, Exhaust - Flange Type				$(5/16-18 \times 3/4")$
	154-2469	1	2-7/16" Long (Spec A)	20			Bracket, Exhaust Manifold
			Begin Spec B		155-2036	1	BGEL (1.97" Long)
	154-2540	1	4-1/4" Long		154-2538	1	BGE (2.31" Long)
	154-2683	1	6-1/4" Long		155-2049	1	BGE (9.19" Long)
	154-2718	1	8" Long	21	800-0005	1	Screw, Cap - Hex Head
6	155-2025	1	Strap, Muffler				$(1/4-20 \times 3/4")$
7			Screw, Cap - Hex Head		526-0018	1	Washer, Flat (1/4")
	800-0030	2	$5/16-18 \times 1-1/4$ " (Spec A	23	821-0029	2	Screw, Hex Washer Head -
			Only)				Self-Lock $(3/8-16 \times 3/4")$
	800-0730	2	5/16-18 × 1"				(Begin Spec B)
8	800-0007	1	Screw, Cap - Hex Head	24	154-2662	1	Tube, Exhaust - 11" Long
			$(1/4-20 \times 1")$				(Use With 154-2663 Bracket)
9			Screw, Cap - Hex Head				(Begin Spec B)
	800~0026	1	Use With-Out Spacer	25	154-2663	1	Bracket, Exhaust (Use With
			(5/16-18 × 3/4")				154-2662 Tube) (Begin Spec B)
	800-0036	1	Use With Spacer	26	370-4027	1	Spacer, Muffler - 2" Long
			$(5/16-18 \times 2-3/4")$				(Used Only On RVs With
10	862-0001	1	Nut, Hex (1/4-20)				6-1/4" Long Exhaust Adapter)
11	850~0040	1	Washer, Lock (1/4")				(Begin Spec B)
12	155-1258	1	Muffler, Arrestor - Spark				
			(Side Inlet, End Outlet)				

5620-0065

Exhaust System - Below Floor Models




Exhaust System - Below Floor Models

5620-0065


							5620-0127
REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	154-2510	1	Manifold Assembly, Exhaust - Front Outlet (Spec A)	4	155-2036	1	Bracket, Exhaust Manifold 1.56 x 1.97"
1A	154-2551	1	Manifold, Exhaust - BGE	5	155-2049 155-1256	1	9.19" Long Clamp, Muffler
1B	154-2627	1	(Begin Spec B) Manifold, Exhaust - BGEL		850-0040	2	Washer, Lock (1/4")
2			(Begin Spec B) Muffler, Arrestor - Spark	7	800-0730	2	Screw, Cap - Hex Head (5/16-18 x 1")
			(Side Inlet, Opposite Side Outlet)	8	800-0026	4	Screw, Cap - Hex Head Exhaust Manifold
	155-2047	1	Spec A				$(5/16-18 \times 3/4")$
	155-2086	1	Begin Spec B	9	850-0045	6	Washer, Lock (5/16")
2A			Muffler, Arrestor - Spark	10	154-2539	1	Tube, Exhaust
			(Side Inlet, Opposite End		155-1015	1	Clamp, Muffler
			Outlet)		155-2174	1	Hanger, Exhaust Pipe
	155-2048	1	Spec A	13	154-1725	2	Gasket, Exhaust Manifold
	155-2085	1	Begin Spec B	14	821-0029	2	Screw, Hex Washer Head - Self
2B	155-2164	1	Muffler, Spark Arrestor -				Lock (3/8-16 x 3/4")
			(Side Inlet, Same End Outlet)	15	526-0130	2	Washer, Flat (1/4")
3	800-0004	2	Screw, Cap - Hex Head (1/4-20 x 5/8")	16	154-2542	1	Gasket, Exhaust

Housing - Below Floor Models




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	405-3332	1	Panel, Housing - Right Hand	13	406-0567	2	Plate, Hinge
2	405-3333	ī	Panel, Housing - Left Hand	14	406-0568	2	Support, Hinge
3	405-3334	1	Panel, Housing - Rear	15	821-0010	6	Screw, Hex Washer Head - Lock
4	405-3453	1	Support, Housing				(1/4-20 × .50")
5	508-0071	3	Grommet, Rubber	16	821-0031	4	Screw, Hex Washer Head - Lock
6	508-0008	2	Grommet, Rubber				(3/8-16 × .75")
7	821-0014	6	Screw, Hex Washer Head - Self	17	526-1518	4	Washer, Flat (7/16")
			Locking $(5/16-18 \times .50")$	18	405-3405	1	Bracket, Housing
8	800-0002	2	Screw, Cap - Hex Head	19	405-3611	2	Brace, Side (22.2" Long)
·	000 0002	-	$(1/4-20 \times .38")$	20	405-3612	1	Brace, Rear (27.35" Long)
9	526-0030	2	Washer, Flat (3/8")	21	821-0033	2	Screw, Hex Head - Lock
10	850-0040	2	Washer, Lock (1/4")				$(7/16-14 \times .75")$
11	403-2280	1	Pan, Drip	22	870-0437	2	Nut, Hex (7/16-14)
12	406-0566	2	Pin, Hinge	23	870-0257	2	Nut, Hex (5/16-18)

This Page is Blank



Generator


REF	PART	QTY	PART	REF	PART	QTY	PART
NO.	NO.	USED	DESCRIPTION	NO.	NO.	USED	DESCRIPTION
1			Armature Assembly, Wound	12			Ring, Collector - Armature
-			(Includes Fan, Ring Gear,		204-0137	1	60 Hertz (BGE Spec A-C and
			Ball Bearing, and Collector				BGEL Spec B)
			Ring)		204-0134	1	50 Hertz
			60 Hertz	13	323-1298	1	Connector, Tab
	201-3172	1	120 Volt (Spec A)	14		4	Lead BGE - Includes Receptable
	201-3252	1	120 Volt (Begin Spec B)		226-2809	1	Connector
	201-3247	1	120/240 Volt, Extended		226-2990	1	BGEL SGEL
			Shaft (Begin Spec C)	15		1	Bushing (1.0 ID x 1-15/32" OD)
	001 0040	4	50 Hertz 110/220 Volt		332-0941	4	Tie, Cable
	201-3246 201-3388-S3	1 1	Code FA, Spec C,D,E	17	212-1274	1	Cover, Brush Block
2	201-3300-33	1	Housing, Stator	18	212 1217	-	Screw, Hex Head - Thread
Z	220-3945	1	Spec A	10			Cutting - W/ET
	220-4097	1	Begin Spec B		815-0194	2	4.0 BGE, Spec A-C
	220-4104	1	Begin Spec C,E			_	(#10-32 × 3/8")
3	220 4104	-	Adapter, Generator		815-0181	2	3.5 BGE, Spec C
•	231-0284	1	Spec A				(#10-32 × 1/2")
	231-0288	ī	Begin Spec B	19	802-1038	1	Screw, Socket - Armature
4			Stator, Wound				Through $(7/16-14 \times 10.23")$
			60 Hertz	20	800-0575	5	Screw, Hex - Flange Head
	220-3883	1	120 Volt				$(3/8-16 \times 1-1/8")$
	220-3885	1	120/240 Volt (Used on BGE		850-0050	4	Washer, Lock (3/8")
			Spec A-C and BGEL Spec B)		862-0003	4	Nut, Hex (3/8-16)
	220-3887	1	120/240 Volt - Used with		315-0591	1	Cover, Transformer
			Extended Shaft	24	815-0337	4	Screw, Cap - Hex Washer Head
			50 Hertz	25			$(1/4-20 \times 3/4")$ Connector, Receptacle
	220-3997-02	1	120/240 Volt	25	323-1299	1	BGE
_	220-3997-01	1	110/220 Volt		332-0819	1	BGEL
5	510-0099	1 1	Bearing, Ball Block, Generator	26	212-1276-03	2	*Spring, Generator Brush
6	212-1285	ı	Brush (Includes Parts		212-1286	1	*Block, With Terminal
			Marked *)	28	526-0018	4	Washer, Flat (1/4" Screw)
7			Screw. Hex Head - Thread	29	020 0010		Fan and Gear, Armature
,			Form				(Includes Ring Gear)
	815-0584	2	#10-32 × 5/8"		205-0156	1	4.0 BGE - Spec A Only
	815-0359	2	#10-32 × 7/8"		205-0165	1	4.0 BGEL - Spec B, 3.5 BGE
8	226-2442	1	Lead (Includes Terminals)				- Spec C
9			Clamp, Stator	30	104-1570	1	Gear, Ring - Spec A Only
	232-3073	4	60 Hertz	31	515-0142	1	Key, Extended Shaft
	232-2955	4	50 Hertz				$(1/4" \times 1")$
	214-0103	2	*Brush, Generator				
11	815-0436	4	Screw, Cap - Hex Washer Head				nto took of the board of the
			$(1/4-20 \times 1/2")$	*	Parts Includ	ied in	212-1285 Generator Brush Block



Control

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	301-8619	1	Gover, Control		320-1549	1	Guard, Breaker - Circuit
2			Board, Circuit - Printed	14			Breaker, Circuit
	300-2784-01	1	BGE		320-1323	1	30 Ampere - 60 Hertz
	300-2943-01	1	BGEL		320-1548-01	1	17 Ampere - 50 Hertz
3			Screw		305-0718	1	Rectifier, Bridge
	812-0062	4	Round Head (#6-32 \times 7/16")		508-0253	2	Bushing (1.0 ID x $1-15/32^{\circ}$ OD)
			(Used on BGE Spec A-C and		508-0251	1	Bushing (.750 ID \times 1-1/8" OD)
			BGEL Spec B)	18	815-0261	2	Screw, Hex Washer Head - Thd
	815-0550	4	Pan Head (#6-32 x 3/8")				Cutting $(1/4-20 \times 1/2")$
			(Used on BGE Spec E and		332-0156	2	Terminal (1/4")
			BGEL Spec D)	20	815-0359	1	Screw, Hex Head - Thread
ЗА	850~0020	4	Washer, Lock (#6) (Used on				Form $(#10-32 \times 7/8")$
			BGE Spec A-C and BGEL Spec B)		332-1993	2	Receptacle, Blue (1/4")
4	321-0287	1	Insulator, Fuse		332-0684	2	Receptable, Black (1/4")
5	308-0852	1	Switch, Rocker	23	812-0061	2	Screw, Round Head
6	321-0298	1	Fuse, 5 Amps - Slo-Blow				(#6-32 × 3/8")
7	321-0266	1	Holder, Fuse		850-0020	2	Washer, Lock (#6)
8			Harness, Wiring	25		6	Receptable (1/4")
			60 Hertz		323-0440	1	Housing, Socket
	338-1931	1	BGE		323-0400	1	Housing, Connector Pin
	338-1932	1	BGEL		98-5260	1	Decal (Emerald I)
	338-2143	1	Begin Spec C,E	31	332-2112	1	Insulator, Terminal -
	338-2031	1	50 Hertz				Start Solenoid
9	815-0194	4	Screw, Hex Head W/ET - Thread		323-1311	1	Connector, 8 Pin
			-Cutting (#10-32 x 3/8")	-	323-1302	8	Pin, Contact
10	332-1815	1	Tab, Terminal	34	323-1312	1	Housing, 8 Pin
11			Screw, Pan Head		332-0819	1	Housing, Connector Push-On
	815-0388	2	60 Hertz (#6-32 x 1/2")				4.0 BGEL - 60 Hertz
	815-0387	2	50 Hertz (#6-32 × 1/4")				(Not Shown)
12	307-2344	1	Solenoid, Start (Includes Nuts And Washers)		357-0030	1	Rectifier, Silicon - CR5 BGEL (Not Shown)

Remote Start Control



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
	300-0985	1	Control Package, Standard -	6	302-0885	1	+Meter, Totalizing - Time
			Remote Starting (Includes	7	302-0888	1	+Meter, Condition - Battery
			Parts Marked *)	8	359-0034	1	+Diode
	300-0986	1	Control Package, Deluxe - Remote Starting (Includes Parts Marked +)		338-1082	1	Harness, Wiring - Remote (Not Illustrated) (Includes Parts Listed Below)
1	815-0385	2	+Screw, Machine - Round Head		338-1082	1	6" Long
	010 0000	~	(#6-32 × 1/2")		338-1080	1	10 Feet Long
2	860-0005	2	+Nut, Hex Head (#6-32)		338-1081	1	30 Feet Long
3	301-3566	ī	*Panel, Control		323-0400	1	Housing, Connector
4	308-0341	ī	*+Switch, Rocker		323-0500	1	Pin, Contact
5	301-3606	1	+Panel, Control				

^{* -} Parts Included In 300-0985 Control Package. + - Parts Included In 300-0986 Deluxe Control Package.

Labels, Paint, Thread Sealant and Gasket Kits

REF	PART NO.	QTY USED	PART DESCRIPTION	REF	PART NO.	QTY USED	PART DESCRIPTION
110.	NO.	UULD	DESORT! TION	110.	10.	UOLD	DESONT? I TON
	98-5313	1	Label, Warning (Battery Cables)		101-0415	1	+Gasket, Rear Bearing Plate
	98-5142	1	Label, Warning (Fire Hazard)		102-1200	1	+Gasket, Oil Base
	98-5347	1	Label, Danger (High Voltage)		103-0408	1	+Gasket, Gear Cover
	98-5260	1	Decal (Emerald I) - 60 Hertz		110-1921	3	+Gasket, Valve Cover
	98~5845	1	Decal (Emerald I) - 50 Hertz		110-3181	2	+Gasket, Cylinder Head
	98-5713	1	Label, Warning (Extended Shaft)		120-0161	1	+Gasket Kit, Oil Pump
:	98-5641-01	3	Label, Performer - 18 Horsepower		122-0375	1	+Gasket, Oil Filter Adapter
	98~5335	1	Label, Preheat (Gasoline)		140-1087	1	+Gasket, Air Horn
			(Spec A-C)		141-0281	1	+Gasket, Carburetor (BGEL)
	518-0452	· 1	Sealant, Thread (50cc Bottle)		154-1725	2	+Gasket, Exhaust Manifold
	525-0305	1	Paint, Enamel Touch-Up		160-1150	1	+Gasket, Breaker Box
			Green (Non-Metallic) 13 oz.		509-0008	1	+Seal, Oil (Governor Shaft)
			Pressurized Can		509-0040	1	+Seal, Oil (Gear Cover)
	518-0347	1	Loctite, Bottle (250cc)		509-0041	1	+Seal, Oil (Bearing Plate)
	168-0178	1	Kit, Gasket - Carbon Removal		509-0168	2	+Seal, Oil (Valve)
			(Includes Parts Marked *)		154-2495	2	+Gasket, Intake Manifold (BGE)
	110-1921	3	*Gasket, Valve Cover		154-1446	2	+Gasket, Intake Manifold (BGEL)
	110-3181	2	*Gasket, Cylinder Head		154-2061	1	+Gasket, Exhaust
	154-1725	2	*Gasket, Exhaust Manifold		154-2542	1	+Gasket, Exhaust
	509-0168	2	*Seal, Oil (Valve)		141-0950	1	+Gasket, Carburetor Mounting
	154-2495	2	*Gasket, Intake Manifold (BGE)				(BGE)
	154-1446	2	*Gasket, Intake Manifold (BGEL)		509-0210	2	+Seal, Intake Valve
	509-0210	2	*Seal, Intake Valve				
	168-0181	1	Kit, Gasket - Engine Complete				
			(Includes Parts Marked +)	* -	Parts Include	ed in	168-0178 Gasket Kit.
				+ -	Parts Includ	ed in	168-0181 Gasket Kit.

Part No.	Page	Part No.	Page	Part No.	Page	Part No.	Page
98-5142	43	110-0904	7	120-0140	7	141-0700	19
98-5260	41	110-1808	5	120-0140	15	141-0701	18
98-5260	43	110-1824	5	120-0161	7	141-0701	19
98-5313	43	110-1824-02	5	120-0161	43	141-0702	19
98-5335	15	110-1824-05	5	120-0398	7	141-0703	19
98-5335	43	110-1824-10	5	120-0491	7	141-0708	18
98-5347	43	110-1824-25	5	120-0735	5	141-0708	19
98-5641-01	43	110-1879-01	5	122-0320	12	141-0710	13
98-5713	43	110-1921	43	122-0360	12	141-0710	19
98-5845	43	110-1935	5	122-0360-50	12	141-0711	18
101-0405	5	110-1955	5	122-0375	43	141-0711	19
101-0415	43	110-3181	5	122-0645	12	141-0713	19
101-0432	5	110-3181	43	122-0774	12	141-0736	18
101-0432-02	5	110-3213	5	123-1173	5	141-0741	19
101-0432-10	5	110-3214	5	123-1174	5	141-0799	19
101-0432-20	5	110-3479	5	123-1175	5	141-0919	18
101-0432-30	5	110-3480	5	123-1417	5	141-0919	19
101-0439	5	110-3485	5	123-1615	15	141-0920	19
101-0450	5	110-3487	5	123-1615	17	141-0921	19
101-0450-02	5	110-3508	5	123-1616	11	141-0923	19
101-0450-10	5	110-3509	5	123-1625	11	141-0924	18
101-0450-20	5	110-3510	7	123-1649	5	141-0924	19
101-0450-30	5	110-3511	5	134-2100	15	141-0927	19
101-0782	5	110-3515	5	134-4342	9	141-0928	19
102-0743	11	110-3526	5	134-4348	31	141-0932	17
102-0938	11	110-3527	5	134-4352	31	141-0932	18
102-1200	43	110-3604	5	134-4353	31	141-0934	18
102-1286	11	110-3709	5	134-4354	31	141-0935	18
102-1387	11	112-0186	7	134-4463	31	141-0936	18
103-0408	43	112-0186-05	7	140-1087	15	141-0937	18
103-0772	13	112-0186-10	7	140-1087	20	141-0938	18
103-0810	13	112-0186-20	7	140-1087	43	141-0939	18
104-0032	9	112-0186-30	7	140-1889	15	141-0940	18
104-0043	9	112-0186-40	7	140-1889	17	141-0942	19
104-0170	9	112-0229	7	140-1891	15	141-0950	15
104-0575	5	113-0189	7	140-1891	17	141-0950	43
104-0776	5	113-0189-05	7	140-1894	15	145-0561	15
104-1570	39	113-0189-10	7	140-1894	17	145-0562	15
104-1583	9	113-0189-20	7	140-1919	15	146-0449	20
105-0332	8	113-0189-30	7	140-2308	17	146-0450	20
105-0541	8	113-0189-40	7	141-0077	18	146-0453	20
105-0637	8	114-0022	13	141-0077	19	146-0455	15
110-0197	5	114-0240	7	141-0281	17	146-0455	19
110-0197-02	5	114-0257	7	141-0281	18	146-0455	20
110-0197-05	5	114-0257-10	7	141-0281	19	146-0457	20
110-0197-10		114-0257-20	7	141-0281	20	148-0890	17
110-0197-25	5	114-0257-30	7	141-0281	43	148-0893	17
110-0539	5	115-0006	5	141-0698	18	148-0896	17
110-0639	5	115-0006-02	5	141-0698	19	148-0897	17
110-0893	5	115-0006-05	5	141-0700	18	148-0898	17

Part No.	Page						
148-0903	17	154-2542	35	167-1615-01	22	220-4104	39
149-1929	15	154-2542	43	167-1615-06	22	226-2426	24
149-1994	15	154-2551	33	168-0178	7	226-2442	39
149-2032-01	17	154-2551	35	168-0178	43	226-2753	27
149-2082	15	154-2627	17	168-0181	7	226-2754	27
149-2084	15	154-2627	33	168-0181	43	226-2809	39
149-2110	15	154-2627	35	191-1038	25	226-2980	12
150-0075	8	154-2662	33	191-1039	25	226-2990	39
150-0078	8	154-2663	33	191-1040	25	231-0284	39
150-0096	21	154-2683	33	191-1041	25	231-0288	39
150-0939	21	154-2718	33	191-1048	25	232-2955	39
150-1187	13	154-2745	17	191-1156	25	232-3073	39
150-1519	8	154-2746	33	191-1359	25	300-0985	42
150-1520	8	155-1015	33	191-1599	24	300-0986	42
150-1612	21	155-1015	35	191-1599	25	300-2784-01	41
150-1957	21	155-1239	33	191-1633	25	300-2943-01	41
150-1958-02	21	155-1256	35	191-1667	24	301-3566	42
150-1998	13	155-1258	33	191-1667	26	301-3606	42
150-2002	13	155-1485	33	191-1776	26	301-8619	41
150-2102	21	155-2025	33	191-1781	26	302-0885	42
153-0554	15	155-2026	33	191-1784	26	302-0888	42
153-0555	15	155-2036	33	191-1785	26	304-0015	27
153-0556	15	155-2036	35	191-1786	26	304-0044	27
153-0557	15	155-2040	31	191-1817	26	304-0772	27
153-0557	17	155-2047	35	191-1818	26	304-0773	27
153-0558	15	155-2048	35	191-1819	26	305-0718	41
153-0561	15	155-2049	33	191-1820	26	307-1886	17
153-0563	15	155-2049	35	191-1821	26	307-2344	41
153-0567	15	155-2085	35	191-1822	26	307-2478	17
153-0571	15	155-2086	35	201-3172	39	307-2501	17
153-0576	15	155-2164	35	201-3246	39	307-2559-01	17
153-0577	15	155-2174	33	201-3247	39	308-0341	42
153-0578	. 15	155-2174	35	201-3252	39	308-0852	41
153-0579	15	160-1150	22	201-3388-53	39	309-0322	12
154-1446	43	160-1150	23	204-0134	39	312-0246	23
154-1725	35	160-1150	43	204-0137	39	312-0249	22
154-1725	43	160-1151	23	205-0156	39	315-0591	39
154-2061	33	160-1183	23	205-0165	39	315-0605	28
154-2061	43	160-1303	22	212-1274	39	315-0645	28
154-2447	15	160-1314	23	212-1276-03	39	315-0646	28
154-2447	17	160-1316	23	212-1285	39	320-1323	41
154-2462	33	160-1317	23	212-1286	39	320-1548-01	41
154-2469	33	160-1325	22	214-0103	39	320-1549	41
154-2495	15	160-1325	23	220-3883	39	321-0266	41
154-2495	43	160-1328	23	220-3885	39	321-0287	41
154-2510	35	166-0554	22	220-3887	39	321-0298	41
154-2538	33	166-0747	22	220-3945	39	323-0400	41
154-2539	35	166-0772	22	220-3997-01	39	323-0400	42
154-2540	33	167-0263-01	22	220-3997-02	39	323-0440	41
154-2542	33	167-1605-02	22	220-4097	39	323-0500	42

Part No.	Page	Part No.	Page	Part No.	Page	Part No.	Page
323-1298	39	405-3333	36	509-0196	28	526-1518	36
323-1299	39	405-3334	36	509-0210	5	740-1004	7
323-1302	41	405-3405	36	509-0210	43	740-1006	17
323-1311	41	405-3453	36	510-0013	13	800-0002	36
323-1312	41	405-3611	36	510-0014	13	800-0004	35
331-0009	28	405-3612	36	510-0015	8	800-0005	33
332-0046	28	406-0566	36	510-0099	39	800-0007	7
332-0156	41	406-0567	36	515-0001	8	800-0007	33
332-0418	28	406-0568	36	515-0001	9	800-0010	5
332-0418	28	501-0525	17	515-0142	39	800-0017	15
332~0529	41	502-0002	15	515-0263	9	800-0017	17
332-0684	41	502-0054	17	516-0072	5	800-0026	33
332-0819	39	502-0313	15	516-0130	13	800-0026	35
332-0819	41	502-0838	17	516-0141	5	800-0028	12
332-0941	28	502-0871	15	517-0048	5	800-0030	33
332-0941	39	502-0927-01	17	517-0067	7	800-0033	15
332-0942	27	502-0928-01	17	517-0223	15	800-0033	17
332-1815	41	502-0929-01	17	517-0283	31	800-0036	33
332-1993	28	502-0932-01	17	518-0006	21	800-0048	31
332-1993	41	502-0933-01	17	518-0014	9	800-0051	5
332-2112	41	502-0935	17	518-0311	7	800-0052	24
332-2431	15	502-0965-01	17	518-0347	43	800-0058	11
332~2572	15	503-0183	15	518-0387	15	800-0540	5
332-2699	28	503-0183	17	518-0450	15	800-0545	13
332-2748	24	503-1133	15	518-0452	43	800-0571	5
336-2378	22	503-1133	17	518-0459	15	800-0572	5
336-2378	23	503-1190	17	518-0466	15	800-0575	5
336-9679	17	503-1252	15	525-0305	43	800-0575	39
337-2229	28	503-1336	15	526-0002	15	800-0730	33
337-2311	11	503-1337	15	526-0003	17	800-0730	35
337-2311	31	503-1345	15	526-0008	17	801-0049	7
338-1080	42	503-1351	15	526-0017	9	801-0050	7
338-1081	42	503-1365	17	526-0018	5	802-0034	22
338-1082	42	504-0150	11	526-0018	15	802-0034	23
338-1931	41	505-0110	11	526-0018	17	802-1038	39
338-1932	41	505-0266	11	526-0018	28	803-0071	5
338-2031	41	505-0274	17	526-0018	33	812-0061	27
338-2143	41	508-0008	36	526-0018	39	812-0061	41
357-0030	41	508-0071	36	526-0030	36	812-0062	41
359-0034	42	508-0251	41	526-0063	7	815-0046	13
370-4027	33	508-0253	39	526-0065	12	815-0176	17
402-0547	11	508-0253	41	526-0065	13	815-0181	39
402-0549	11	509-0008	13	526-0066	7	815-0194	12
402-0597	11	509-0008	43	526-0122	5	815-0194	28
402-0602	11	509-0040	13	526-0130	35	815-0194	39
403-1523	31	509-0040	43	526-0240	11	815-0194	41
403-2218	11	509-0041	5	526-0251	5	815-0235	28
403-2280	11	509-0041	43	526-0324	11	815-0261	15
403~2280	36	509-0096	11	526-0325	11	815-0261	17
405-3332	36	509-0168	43	526-0356	9	815-0261	17
			-				

Part No.	Page	Part No.	Page	Part No.	Page	Part No.	Page
815-0261	22	821-0029	35				
815-0261	27	821-0031	11				
815-0261	31	821-0031	36				
815-0261	33	821-0033	36				
815-0261	41	850-0020	41				
815-0290	28	850-0038	22				
815-0337	28	850-0038	23				
815-0337	39	850-0040	17				
815-0340	27	850-0040	24				
815-0358	23	850-0040	25				
815-0359	39	850-0040	33				
815-0359	41	850-0040	35				
815-0370	17	850-0040	36				
815-0370	22	850-0045	15				
815-0370	27	850-0045	33				
815-0385	42	850-0045	35				
815-0387	41	850-0050	5				
815-0388	41	850-0050	11				
815-0436	39	850-0050	24				
815-0499	33	850-0050	39				
815-0531	17	850-2005	22				
815-0550	41	856-0006	15				
815-0570 815-0583	25 27	856-0008 856-0008	11				
815-0583		856-0008	28				
815-0584 815-0587	39 15	856-0010 860-0005	31 4 2				
815-0587	17	862-0001	24				
815-0590	15	862-0001	33				
815-0590	17	862-0003	24				
815-0591	15	862-0003	39				
815-0591	17	862-0015	15				
815-0592	15	862-0015	17				
815-0610	15	870-0131	21				
815-0610	28	870-0196	27				
815-0647	17	870-0221	17				
815-0657	11	870-0257	36				
820-1077	13	870-0302	7				
821-0005	17	870-0328	13				
821-0009	15	870-0421	15				
821-0009	31	870-0433-03	28				
821-0010	11	870-0437	36				
821-0010	31	870-1183	27				
821-0010	36	898-1193-03	28				
821-0014	11						
821-0014	31						
821-0014	36						
821-0016	11						
821-0016	31						
821-0029	11						
821-0029	33						

SPECIAL PARTS LIST

SPECIAL PARTS LIST FOR MODE FOR STANDARD PART (PARTS CATALOG ALSO COM	S REFER TO	CATALOG_ ENTS FOR MAJO	965-0230	26100A KEY NO. ATURES LISTED BE 611-1174
PART NO: QTY: DESCRIPTIO	Ŋ	PART NO.	en e	DESCRIPTION
ABOVE FLOOR MOUNTING				

SPECIAL PARTS LIST FOR MODEL 4.0BGE FOR STANDARD PARTS REFER TO (PARTS CATALOG ALSO CONTAINS COMPONENTS)	CATALOG_	苦 计三字字符记记令 化热燃料的汽车 化	Z6100B KEY NO
	AGRAM NO.		1174
PART NO. QTY. DESCRIPTION	PART NO.	ary.	DESCRIPTION
	e V		
ABOVE FLOOR MOUNTING			

SPECIAL PARTS LIST FOR MODEL4		SPEC _	26100C
FOR STANDARD PARTS REFI			KEY NÖ. <u> </u>
(PARTS CATALOG ALSO CONTAINS C	G DIAGRAM NO.	OR OPTIONAL F 611-11	84240000
PART NO. QTY. DESCRIPTION	PART NO.		DESCRIPTION
lagi palaming ng manganan ang mangan tang mga mangan mangan kanan na mangan ang mangan kanan kanan mangan manga Tang mga mga mga mga mga mga mga mga mga mg	neverineis di majoristi i pristi entre englis e de la desir de la desir de la dela dela dela dela dela dela del	and faith laife	
ABOVE FLOOR MOUNTING.			
	4		
	1		

Above Floor Mounting	PART NO. QTV. DESCRIPTION
Above Floor Mounting	
Above Floor Mounting	

DATED 1/13/87 REVISED PAGE 1 OF 1

SPECIAL PARTS LIST FOR MODEL 4.0 BGE-1R SPEC 26100E
FOR STANDARD PARTS REFER TO CATALOG 965-0232 KEY NO.
OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

WD: 611-1174

PART NO. QTY. DESCRIPTION PART NO. QTY. DESCRIPTION

Above Floor Mounting

SPECIA	L PARTS LIS	T FOR MODEL	4.0BGE-1R	SPEC _	26101A
			FER TO CATALOG_	965-0230	KEY NO
	(PARTS CAT	ALOG ALSO CONTAINS	COMPONENTS FOR MAJO		
		WIR	ING DIAGRAM NO.	611-1	174
PART NO.	QTY.	DESCRIPTION	PART NO.	ату.	DESCRIPTION
			1 /.		
ABOVE FLO	OR MOUNTING				
			1		
			j		

FOR STANDARD PARTS REFER TO CATALOG 965-0230 KEY NO (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BEI WIRING DIAGRAM NO. 611-1174	SPECIA	L PARTS LI	ST FOR MODEL	4.0BGE-1R	SPEC _	26101B
WIRING DIAGRAM NO. 611-1174 PART NO. QTY. DESCRIPTION PART NO. QTY. DESCRIPTION		FOR ST	ANDARD PARTS REF	ER TO CATALOG_	965-0230	
PART NO. QTY. DESCRIPTION PART NO. QTY. DESCRIPTION		(PARTS C	ATALOG ALSO CONTAINS	COMPONENTS FOR MAJO		
			WIRI	NG DIAGRAM NO	DIII-I	
BELOW FLOOR MOUNTING	PART NO.	QTY.	DESCRIPTION	PART NO.	OTY.	DESCRIPTION
BELOW FLOOR MOUNTING	arada a amila dan istan istan arada indin indin indin indin	<u>aintinius (antiologis (1890) (1890) (1891) </u>			i jain martani irra <u>uni irriya ayana ai lajirtaa fandaastan</u> (antari) d a	a de principal de la companya de la companya de la companya de porte englis de la companya de la companya de l
BELOW FLOOR MOUNTING						
	REI OV	V EL OOR MOL	INTING			
	DLLOV	VI LOOK WO	31111110			
l l						

SPECIAL	PARI	S LIST FOR MODEL4.0	BGE-1R	SPEC_	26101C
	2000 000 000 000	R STANDARD PARTS REFER	9. "		KEY NO
	(PAH		DIAGRAM NO.	SHEET STREET	
PART NO.	QTY.	DESCRIPTION	PART NO.	OTY.	DESCRIPTION
BELOW	FLOOF	R MOUNTING			
201-3252	1	Armature Assembly, Wound (Includes parts Marked *)			
205-0165 204-0137 510-0099	1	*Fan and Gear Assembly *Ring, Collector *Bearing, Ball			

SPECIA	I PARTS I	IST FOR MODEL4.	DBGE-1R	SPEC	26101D
A PART IN A SALAR		ANDARD PARTS REFER			KEY NO
	(PARTS C	ATALOG ALSO CONTAINS CO	MPONENTS FOR MAJ		
		WIRING	DIAGRAM NO.	611-xxxx	teral bridge for the street and control or desired to the street of the
PART NO.	QTY.	DESCRIPTION	PART NO.	ату.	DESCRIPTION
البائدة المائية	aniinin iniiniini	atura kanangan kanangan kanang bermalan periodi di Arbit dan dinan di Kanangan dan banangan dan di Arbit pinan	manusta para para madalah mendelah para di mendelah bersilah di mendelah bersilah di mendelah bersilah bersilah	ingi, ang at an uniperiorgen airgister (mineriorgen mi 20)	
REI OV	V FLOOR MO	II INITING			
DLLOV	VI LOOK IVIO	ONTING			
			1		
			-		

SPECIA	L PARTS I	IST FOR MODEL4.0	DBGE-1R	SPEC_	26101E
		ANDARD PARTS REFER			KEY NO
	(PARTS C	ATALOG ALSO CONTAINS CO	MPONENTS FOR MAJ		
		WIRING	DIAGRAM NO.	611-1174	
PART NO.	QTY.	DESCRIPTION	PART NO.	оту.	DESCRIPTION
ntere de ser comitio e tenir e estrat resista altre as tradecidades dificación de de	<u>ani ini mai kanta dhini kata tali na maga ta mata ka ka na mata </u>				
BEI OV	V FLOOR MO	UNTING			
52201					

SPECIA	L PARTS I	IST FOR MODEL4.0	DBGE-1R	SPEC	26102A
· Nation No. 20 And American		ANDARD PARTS REFER			KEY NO
	(PARTS C	ATALOG ALSO CONTAINS CO	MPONENTS FOR MAJ		
		WIRING	DIAGRAM NO.	611-1174	mingrad - Hermanian de la contra de propinsión de la profesional de la contra del la contra de la contra de la contra del la contra de la contra del
PART NO.	QTY.	DESCRIPTION	PART NO.	оту.	DESCRIPTION
ann fan se en it te de kenidd kenidd genis út út en ee te fan het de ee it it in die de	ani indiana ing katha dhina (1994 telisma ang grap terutana na mata	etario de autorio e que moior de esta dias el Corple de Mario de Aligado de Corple de Aligado de Aligado de Al			
ABOVE	E FLOOR MO	UNTING	4.		

SPECIA	L PARTS	S LIST FOR MODE	4.0BGE-1	R	SPEC	26109A
		STANDARD PART			aja lama milla	KEY NO
	(PART	S CATALOG ALSO CON	TAINS COMPONE	NTS FOR MAJO		
			WIRING DIAG	RAM NO.	611-1	
PART NO.	QΤY.	DESCRIPTIO		PART NO.	оту.	DESCRIPTION
BELOV	V FLOOR I	MOUNTING				
403	-2332	1 Pan, Drip				

SPECIA		S LIST FOR MODEL 4.0		SPEC	26109B KEY NO
	5,000,000,000	R STANDARD PARTS REFER TS CATALOG ALSO CONTAINS COM WIRING	3		ATURES LISTED BE
PART NO.	QTY.	DESCRIPTION	PART NO.	OT-Y	DESCRIPTION
Manufa	ctured 1	for: WINNEBAGO			
BELOW	/FLOOF	RMOUNTING			
403-233 201-325		Pan, Drip Armature Assembly, Wound (Includes parts Marked *)			
205-016 204-013 510-009	7 1	*Fan and Gear Assembly *Ring, Collector *Bearing, Ball			
	furnishe not nec	systems may or may not be ed by Onan and components are essarily interchangeable n Onan and Winnebago			

SPECIA		S LIST FOR MODEL		SPEC 965-0230	26109C KEY NO
	(PAR	TS CATALOG ALSO CONTAINS O WIRIN	COMPONENTS FOR MAJO IG DIAGRAM NO.	OR OPTIONAL FI	
PART NO.	QTY.	DESCRIPTION	PART NO.	OTY-	DESCRIPTION
Manufa	ctured 1	for: WINNEBAGO			
BELOW	/FLOOF	RMOUNTING			
403-233 201-325		Pan, Drip Armature Assembly, Wound (Includes parts Marked *)	d		
205-016 204-013 510-009	7 1	*Fan and Gear Assembly *Ring, Collector *Bearing, Ball			
	furnishe not nec	systems may or may not be d by Onan and components essarily interchangeable n Onan and Winnebago			

SPECIA	FOR ST		REFER TO CATALOG		26109D KEY NO
	(PARTS C		INS COMPONENTS FOR MAJ	OR OPTIONAL FE 611-XXXX	ATURES LISTED BEI
PART NO.	QTY.	DESCRIPTION	PART NO.	OTY.	DESCRIPTION
ABOVE	E FLOOR MO	UNTING			
403	3-2332 1	Pan, Drip			

SPECIA	SPECIAL PARTS LIST FOR MODEL				26109E 2 KEY NO. FEATURES LISTED BE 1174	
PART NO.	QTY.	DESCRIPTION	PART NO.	ОТУ	DESCRIPTION	
Manufa	actured for:	WINNEBAGO				
BELOV	V FLOOR MO	UNTING				
403	-2332 1	Pan, Drip				
NOTE:	furnished by not necessa	tems may or may no Onan and componer rily interchangeable an and Winnebago				

CDECIA	4 DADTO	IST FOR MODEL	4.0 BGEL-1R	SPEC	26110B
SHECK			FER TO CATALOG_		KEY NO
	The second secon		COMPONENTS FOR MAJO	OR OPTIONAL FE	ATURES LISTED BEI
		WIR	ING DIAGRAM NO.	611-1174	
PART NO.	QTY.	DESCRIPTION	PART NO.	ату.	DESCRIPTION
ABOVE	FLOOR MO	UNTING			
			*		

SPECIA	L PARTS LI	ST FOR MODEL4.0) BGEL-1R	SPEC	26110C
And the state of t		ANDARD PARTS REFER	TO CATALOG_	965-0231	KEY NO
	(PARTS CA	ITALOG ALSO CONTAINS COI	MPONENTS FOR MAJO		ATURES LISTED BEI
		WIRING	DIAGRAM NO.	611-1174	Alengtical and the property and the control of the property of the control of the
PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
فالمتنا والمتنا	aintinina (ing) athir (1914) an magarata (an an an an an an	eren kantan da en			
4 D () / [INITINIO			
ADOVE	FLOOR MOU	INTING			
			-		

SPECIA	I PARTS I I	ST FOR MODEL4.0) BGEL-1R	SPEC	26110D
SHEO!		NDARD PARTS REFE		965-0232	KEY NO
		TALOG ALSO CONTAINS CO	Y. T.		
		WIRING	DIAGRAM NO.	611-1174	
PART NO.	ατγ.	DESCRIPTION	PART NO.	ОТ Ү.	DESCRIPTION
ABOVE	FLOOR MOU	NTING	·.		

SPECIA	L PARTS LI	ST FOR MODEL4.0	BGEL-1R	SPEC	26111B
The state of the s		ANDARD PARTS REFER	TO CATALOG_	965-0230	KEY NO
	(PARTS C	ATALOG ALSO CONTAINS COI	MPONENTS FOR MAJ		ATURES LISTED BEI
		WIRING	DIAGRAM NO.	611-1174	And the first interest and the second of
PART NO.	OTY.	DESCRIPTION	PART NO.	оту.	DESCRIPTION
ene la ser assista de la ciente en esta de la ser a la ciente en el ciente de la ciente de la ciente de la cie	ini ini kaci ahin ka Maisa ahija atau kaci an arabah				
DEI OV	V FLOOR MOI	INTING			
BELOV	V FLOOK WO	UNTING			
			1		

SPECIA	L PARTS LI	ST FOR MODEL4.0	BGEL-1R	SPEC	26111C
	FOR ST	ANDARD PARTS REFER	y	965-0231	KEY NO
	(PARTS C	ATALOG ALSO CONTAINS COI	MPONENTS FOR MAJO		ATURES LISTED BEI
		WIRING	DIAGRAM NO.	611-1174	niced in a law in the
PART NO.	QTY.	DESCRIPTION	PART NO.	ату.	DESCRIPTION
		ppperantes, uma vein den de initia ette que libida (note pende initia) en en frances en en en entre tentinativ	namanga palipunan da didina sainta anasina ina sainta sainta sainta da didina sainta da didina da didina da di	eligini, mje je postava i grava postavi je se je postavi i konferenci me konstanci. Postava	n en de seus de la film de la contracte de la c
BELOV	V FLOOR MOI	JNTING			
			į		
			· <u>.</u>		

SPECIA		ST FOR MODEL	4.0 BGEL-1R	SPEC 965-0232	26111D
		ANDARD PARTS RE	COMPONENTS FOR MAJO	nda en	KEY NO
	(PANIS CA		NG DIAGRAM NO.	611-1174	ATORES EIGHT
PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
BELOV	V FLOOR MOU	JNTING			

OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.
WD: (Eng) 611-1176

PART NO.	QTY		9) 611-1176		Y. DESCRIPTION
May out congress and Constitute this constitute is a series and a residence of a constitute of the day	301-1-11-0-1-1-1-1-1-1-1-1-1-1-1-1-1-1-1	or: 'Time Manufacturing	editan jeunt a ur druge a manufuga nive su inte a un line line line line me mil a payla et ma a maa an		arenamendende kantsen en mar utvorspressiöre affici källindebiten fören ellindraga sinn effikte allebite
rangiac care	ru ru	of the Handractoring			
		a Application			
Above Floor	MO	unting			
201-3247	1	Armature Assembly,	402-0602	1	Isolator, Vibrati
•		Wound (Includes Parts			Generator End
		Marked *) .	337-0036	1	Strap, Ground
205-0165	1	*Fan And Gear Assembly	191-1681	1	Regulator, 35 Amp
204-0137	1	*Ring, Collector	301-9966	1	Bracket Assembly,
510-0099	1	*Bearing, Ball	·		Regulator
220-3885	1	° Stator Assembly, Wound		7	Relay, 30 Ampere
520-0961	1	Stud, Armature Exten.	338-2143	1	Harness, Printed
320-1321	1	Breaker, Circuit			Circuit Board
320-1365	1	Cover, Circuit Breaker			(Includes Part
323-1216	7	Body Connector - Fuse	794		Marked #).
		Holder	332-0.147	1	#Terminal, Solderl
332-2423	1,	·	No.		(#10)
3 3 2 - 1 1 9 4	1		33/2-0887		#Terminal, Solderl
		Holder	3/2-2697		#Terminal, Ring
321-0165	1	Holder Assembly, Fuse	\$ 32-2572	1	#Terminal, Recepta
191-1630	1	Starter(Complete)			(.250)
S.		(Includes Parts	332-0807	7	#Terminal, Solder
	_	Marked +)			(#10)
191-1817		+Cover, Spring	332-0805	- 1	#Terminal, Solder
191-1818		+Retainer, Clutch	000 0000		(#6)
191-1785		+Washer	332-0819		#Insulator, Push-c
191-1784	1	+Clutch And Spline Assy	332-2715	1	#Terminal, Recepta
191-1783	L.	+Brush And Terminal			
191-1782	2	Assy. (Negative)			
191-1702	l.	+Brush And Terminal			
191-1781	49	Assy. (Positive)			
131-1701	1	+Cap, End (Includes Brushes)			
191-1780	А	+Spring Set, Brush			
191-1779		+Washer, Commutator End			
191-1778		+Washer, Spring			
191-1777		+Washer, Flat			
191-1776	1	+Cap Assembly, Drive			
	'	End			
191-1775	1	+Armature :			
191-1774	1	are the same of th			
191-1819	1	+Gear, Starter			
191-1786	1	+Pin, Roll			
191-1820	•	+Spring, Pinion			
191-1821		+Retainer, Spring			
191-1822		+Washer	,		
300-2943	1				
THE THE THE BOOK MAKE THE TOUR		Circuit			
220-4104	1	Housing, Stator			
अस्तर प्रथम चारा ादो से कुली गावें	•	و عادي من والمراجي غداد الأهماء الما عداد عداد عداد المداد			

PART NO. QTY. DESCRIPTION PART NO. QTY. DESCRIPTION

Manufactured For: Time Manufacturing

RV Application Above Floor Mounting

Above Floor	
201-3247	1 Armature Assembly, Wound (Includes Parts
	Marked *)
205-0165	1 *Fan And Gear Assembly
204-0137	1 *Ring, Collector
510-0099	1 *Bearing, Ball
220-3885	1 Stator Assembly, Wound
515-0142	1 Key, Extended Shaft
898-0780	1 Sleeving, Extended Shaft
503-1544	1 Hose, Preheater
402-0602	2 Isolator, Vibration -
, ·	Generator End
191-1681	1 Regulator, Voltage - 30 Ampere
301-9966	1 Bracket, Voltage
	Regulator Mounting
321-0277	1 Holder, Fuse
307-1886	1 Relay, 30 Ampere
338-2143	1 Harness, Printed
	Circuit Board
	(Includes Parts
· .	Marked #)
332-0147	1 #Terminal, Solderless (#10)
332-0887	1 #Terminal, Solderless
332-2697	1 #Terminal, Ring
332-2572	1 #Terminal, Receptable (.250)
332-0807	1 #Terminal, Solderless (#10)
332-0805	1 #Terminal, Solderless (#6)
332-0819	1 #Insulator, Push-on
332-0619	1 #Thsulator, rush-on 1 #Terminal, Receptable
98-5713	1 Label, Caution -
^^ ====	Regulator Bracket
98-5845	1 Silkscreen, Model
	Identification

PECIAL PA	ARTO LIST	FOR MODEL	3.5BGE-53BR	SPE	29236C
OPTIO	R STANDAI	RO PARTS REFER	ISTED BY GROU	<u>965-0230</u> P NO. BELO	WHEN USED
ganitanto-riprisante-riprisante-riprisante-riprisante-riprisante-riprisante-riprisante-riprisante-riprisante-r			ng) 611-1177	garage and control part (principle and control part of the control part of the control part of the control part	gages que que esta esta de la cita de como como con deser los citas de como que a como de como como como como como como como com
PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Lea gami ang kasa ing ang pang makang Canalus prog sa ak katal					
bove Floo	r Mounting				
	à				
		•			: : : : : : : : : : : : : : : : : : :
	·				
			ľ		

DATED 1/13/87

REVISED

PAGE 1 OF 1

SPECIAL PARTS LIST					
- OPTIONAL GROUPS		LISTED BY GROU	IP NO. BEL	KEY NO.	
	611-1177				
PART NO. QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION	
MANUFACTURED FOR: LEE'	S				
Above Floor Mounting					
				R.	
			daly		
			or .		
	•				
		*			2 · · · · · · · · · · · · · · · · · · ·
		:		q •	
				• • • • • • • • • • • • • • • • • • •	•
	•			•	
		end.			
		•			
					ř.
	**************************************				in the second of the second o
	era	out.	i de esta di pa r e.		79
					· · · · · · · · · · · · · · · · · · ·
		5			
	W		•		
		0.9	<u></u>		
· · · · · · · · · · · · · · · · · · ·					
	Gr.			og græger det gleder. Kommune det kommune	
			8		
		H y			
	v.				
	्राप्त अनुसारिक स्थापन स्थ स्थापन स्थापन			.com/UserFriendlyC	

SPECIAL PARTS LIST FOR MODEL 4.0BGE-53CR SPEC 29236D FOR STANDARD PARTS REFER TO CATALOG 965-0231 KEY NO. OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO BELOW WHEN USED. WD: 611-XXXX PART NO." QTY. DESCRIPTION PART NO. QTY. Above Floor Mounting

DATED 1/13/87

REVISED

SPECIAL P	ARTS LIST	FOR MODEL	3.5BGE-53BF	SPEC_ 3 965-0230	29237¢ KEY NO
OPTIO	NAL GROUPS	IN CATALOG ARE L	ISTED BY GRO	UP NO. BELOW!	WHEN USED.
	WD:	El	ng) 611-1177		talan magazina and the particle of the parameter of the second of the se
PART NO.	QTY.	DESCRIPTION	PART NO.	QTY. D	ESCRIPTION
	al .				
	* 1				
	and the second second				
Below Floo	r Mounting				
		•			
		•		2	
	e.	*			
		, a l	The state of the s	•	-
				a a	
					ed Z
**.*.	and (·
	- <u></u>	T _L		e de la companya de La companya de la co	
•					•
	3				-
. \$				*	
·	***	>		,	
	Manager 1		, ii		
	5				
e e e e e e e e e e e e e e e e e e e					
		S			
					The state of the s
	• • • • • • • • • • • • • • • • • • •	•	1		
			,		
· •	***		12 9		
	. d				* %
~					
7					•
		e de la companya de l			•
	, s	$\hat{\mathcal{T}}_{i,j}(g, \hat{x}) = \hat{x}_{i,j}(\hat{x})$	e de la companya de l		
					The state of
	1			P	
		Section 1985		**	
, i					

REVISED

SPECIAL PARTS LIST FOR MODEL

PARTS LIST FOR MODEL 3.58GE-53CR SPEC-FOR STANDARD PARTS REFER TO CATALOG 965-0230 KEY NO. OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

(Eng) 611-1177

PART NO.

Below Floor Mounting

http://stores.ebay.com/UserFriendlyCDs

1/13/87 DATED

REVISED

ART NO. OTY.	DESCRIPTION	PART NO.	QTY. DES	CRIPTION
előw Floor Mountin	g			

http://stores.ebay.com/UserFriendlyCDs

DATED 1/13/87 REVISED PAGE 1 OF 1

SPECIAL PARTS LIST FOR MODEL 4.0 BGE-3CR SPEC 30981E

FOR STANDARD PARTS REFER TO CATALOG 965-0232 KEY NO.

OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

WD: 611-1176

PART NO.	QTY. DESCRIPTION PART NO. QTY. DESCRIPTION
RV Applica Above Floo	
220-3885	1 Stator Assembly, Wound
503-1544	1 Hose, Preheater
402-0602	2 Isolator, Vibration - Generator End
191-1681	1 Regulator, Voltage - 30 Ampere
301-9966	1 Bracket, Voltage Regulator Mounting
321-0277	1 Holder, Fuse
307-1886	1 Relay, 30 Ampere
338-2143	1 Harness, Printed Circuit Board (Includes Parts Marked #)
332-0147	1 #Terminal, Solderless (#10)
332-0887	1 #Terminal, Solderless
332-2697	1 #Terminal, Ring
332-2572	1 #Terminal, Receptable (.250)
332-0807	1°#Terminal, Solderless (#10)
332-0805	1 #Terminal, Solderless (#6)
332-0819	1 #Insulator, Push-on
332-2715	1 #Terminal, Receptable

SPECIAL PARTS LIST FOR MODEL 3.5 BGE-53BR SPEC 29237E

FOR STANDARD PARTS REFER TO CATALOG 965-0232 KEY NO.

OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

WD: 611-1177

PART NO. QTY. DESCRIPTION PART NO. QTY. DESCRIPTION

Below Floor Mounting

FOR STANDARD PARTS REFER TO CATALOG 965-0232 KEY NO.	
OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO, BELOW WHEN USED.	arjenativi seksteri
WD: 611+1177	

PART NO. QTY. DESCRIPTION PART NO. QTY. DESCRIPTION

Below Floor Mounting.